

NOBLELIFT




WARNING

Do not use the forklift before reading and understanding the operating instructions as well as the warning decals on the truck.

Keep for future reference.

FE4P40N, FE4P45N, FE4P50N



Operation and maintenance manual

FEXP type

battery counterbalanced forklift truck

NOBLELIFT INTELLIGENT EQUIPMENT CO.,LTD.

Catalogue

Forward	4
Chapter one Attention when using the forklift truck	5
1、Transportation for forklift.....	5
2、Deposit.....	5
3、Preparation before use.....	5
4、Operation of truck.....	5
5、Battery charging.....	6
Chapter two The main performance parameters of forklift truck	7
I 、 The truck's outline dimension and performance parameters	7
1.The truck's outline dimension	7
2. Technical data	8
II 、 The construction, principle and adjustment of the truck's main parts.....	10
1. Drive system	10
1.1 Drive system (single wheel drive).....	10
1.2 Drive system (double wheel drive).....	16
2. Brake system	16
2.1 Summarize	16
2.2 Brake paddle.....	16
2.3 Brake base pump	17
2.4 Brake staff.....	18
2.5 Parking brake operating device	20
2.6 Gist of dismantlement and regulating for brake staff	20
2.7 Adjusting for Brake pedal	23
2.8 Malfunction and cause	24
2.9 Maintenance	25
3. Steering system	26
3.1 Summary	26
3.2 Full Hydraulic cycloid redirector	26
3.3 Steering axle	27
3.4 Gist for adjustment and maintenance.....	30
3.5 Inspection after rebuilding of steering system	30
3.6 Diagnose of steering system	31
4. Electrical system	32
4.1 Electronic control assembly (Inmotion)	43
5. Battery	43
5.1 Battery safety requirements	43
5.2 Battery use requirements	43
5.3 Battery charging	44
5.4 Installation and replacement of battery.....	46
6. Hydraulic system	46


6.1 Sumarry	46
6.2 Oil pump	46
6.3 Multiway valve	46
6.4 Lift cylinder and lift chains	59
6.5 Tilt cylinder	51
6.6 Hydraulic cylinder	51
6.7 Hydraulic hose	52
6.8Maintenance and adjustment	53
6.9 Fault analysis.....	55
7. Lifting system.....	57
7.1 Summarize.....	57
7.2 Inner and outer mast	57
7.3 Fork carriage	57
7.4 Roller position	58
7.5 Maintenanceandregulation	61
7.6 Instructionsofinstallingaccessaries	61
8. Disassemblingandinstallation.....	61
8.1 Attentions.....	61
8.2Hoistinglocationforpartsdisassembled.....	61
Chapter Three Operation,use and safety for forklift	63
I 、 Driving and operation.....	63
1. Usage of new vehicle.....	63
2. Connection between load and stability	63
3. Load center and load curve	63
4. Forklift stability	63
5. Transportingandloadingforforklift	64
6. Preparation before driving	64
7. Steer.....	64
8. Parking and temporary parking.....	65
9. Usage of battery	66
10. Stacking.....	67
11. Unstacking.....	68
12. Deposit.....	69
II 、 Using instruction ofoperatingdevices.....	69
1. Components,schematicdiagramforoperatingdevices	70
2. Instrument unit	70
3. Switches	70
4. Control	71
5. Bodywork	73
III、 Safety issues.....	75
1Operation place and working environment	75
2. Safety rules	75


3. Truck' s transportation	85
4. Howtoavoidoverturning,howtoprotectyourself	86
5. Safety problem in Maintenance	87
6. Safety problem in battery usage	89
7. Plate	91
Chapter four Truck's regular check and maintenance	92
I 、 The check before operation.....	92
1.Checkingpointandcheckingcontent	92
2. Checking procedure	92
II 、 Check after operation.....	94
III、 Truck cleaning.....	94
1. Truck surface cleaning	97
2. Chains cleaning.....	97
3. Electric system cleaning	97
4. After cleaning	97
IV、 Regular maintenance.....	98
1.Regularmaintenanceschedule	98
2.Regular replacement of key safety parts	103
V 、 Area lubricated and lubricant recommended.....	104
1. Area lubricated	104
2.Lubricant recommended.....	104

Forward

This manual briefly introduces the technical parameters as well as the construction, working principle and the requirements in operation and the maintenance of each main part of the four-wheel battery counter-balanced forklift truck of our company. Before operation, please read the manual carefully to ensure safe and efficient load portage by correct operation and maintenance, and to help the operator to use the battery forklift truck properly so as to make full use of it. It is hoped that the operator and the facility manager read the manual carefully before operation! Please perform strictly according to the attention matters in this manual, drive cautiously, operate carefully, use meticulously. Always make your forklift truck be in the best situation and make full use of it, When lending or assigning the forklift, please bind this manual with it.

To illuminate particularly, the following titles are used in this manual:

1. ---- Regulations that you need to pay attention and have to comply with before operation, if not do so, it should lead to injury on human or damage on equipments and fire.
2.  ---- Regulations that you need to pay attention and have to comply with before operation, if not do so, it should lead to damage on equipments or some sort of injury on human.
3. ---- Something that you have to pay attention before operation.

 The majority of materials that consists of the equipment can be completely recycled. During working, repairing, maintenance and cleaning, there are waste materials have to be collecting and disposing in friendly-environment way under the rules of local government. professional experts must be necessary for dealing with these waste materials (such as hydraulic fluid, old battery and electronic devices) at a specified area, otherwise, the negative effect may harm the environment and human health.

Considering the demands of constantly developing and renewing the products. Manufacturer reserves the right to modify our own products at any moment without notice or incurring in any sanction. It is suggested to get contact with us if users want to know the up to date information of the products. All the information reported herein is based on data at the moment of the publication of the manual.

Chapter one Attentions when using the forklift truck

The operator must always keep in mind the principle of safety first. Conscientiously and cautiously read the maintenance manual. Undergo safe operate and canonical operate strictly following the demand in this manual

1 Transportation for forklift

Pay attention to the following particulars when using container or automobile to convey forklift truck

- (1) Enable parking brake
- (2) Fasten mast and counterweight with steel wire in both two sides; Chock with wedge the front and rear wheels at proper site
- (3) Hoist Lift the forklift according to indication on lifting plate

2 Deposit

- (1) Lower the mast to the lowest position
- (2) Switch off power, Push all the operating rod to vacancy; Pull out power plug
- (3) Stretch hand brake rod
- (4) Chock with wedge front and rear wheels
- (5) When truck is in long-term non-use. Wheels should be overhead. And battery should be boost charged once a month

3 Preparation before use

- (1) Check up all the meters
- (2) Check up tire pressure
- (3) Check up the state of each handle and pedal
- (4) Check up if the voltage of battery is in operating range; and weather the specific density of electrolyte and the altitude of liquid surface are in order
- (5) Check up if the contact of each connector and plug of electrical system is ok
- (6) Check up if the hydraulic liquid, electrolyte or brake fluid is leaking
- (7) Check up the condition of each main fastener
- (8) Check up if the illuminators, signal lamps are in order
- (9) Loosen parking brake
- (10) Try to lift and lower the mast, tilt forward and backward the mast, turn and brake the truck
- (11) Be sure that the polluting level of hydraulic oil is less than 12grade

4 Operation of truck

- (1) Only can the person operate the truck who has been trained and got driver's license
- (2) Operator should wear safe protective shoes, cap, costume in his operation
- (3) Pay attention to the performance and working conditions of mechanics, hydraulic, electrical and MOSFET governor when operating
- (4) Switch on the power, turn on the key, select the position of direction switch, roll the steering wheel to see if the truck is in order, step down the governor pedal slowly, keeping a proper starting acceleration
- (5) Check the voltage meter when the truck is in working, if the value stated in the meter is less than 41V (72V), stop working immediately, charge the battery or change another fully charged battery
- (6) When conveying, the load should not exceed the rated capacity. The separation and position of forks should be appropriate, insert the forks absolutely downside the load, make the load uniformly distributed on the forks; to prevent load from deviation
- (7) When the distance between the load' gravity center and yoke is equal or less than 500mm. The maximum load capacity should be the rated capacity, and when the distance between the load' gravity center and yoke is more than 500mm; the maximum load capacity should be less than the rated capacity
- (8) When forks is bearing load, tilt backwards mast mostly, the yoke should always contact with load; lift forks upto 200mm high from ground before driving
- (9) No standing under forks, no standing on forks when lifting

- (10) The starting speed should not be too fast when starting to lift and lower the load
- (11) No operation of truck and its additions without sitting on the driver's seat
- (12) Push handle immediately to middle position when the mast has tilted forward or backward to the extreme position
- (13) No driving or turning when the mast is lifting
- (14) When travelling, pay attention to passers by, obstacles, irregular road and the clearance of upper side of forklift
- (15) Be careful of travelling on slope, when the angle of slope is more than 10%, travel forward upslope and travel backward downslope. no turning on slope, no loading or unloading when travelling downslope
- (16) Reduce speed when turning on the damp or slick road, take special care and drive slowly when travelling on dock or on temporary board
- (17) Operating high lift range truck of which the lifting height is more than 3m, pay attention to the dropping of the load, and take measures to prevent it when necessary
- (18) Don't convey unfastened or loosely stacked load, be careful when conveying large-size load
- (19) When travelling with load, avoid emergency brake
- (20) When leaving the truck, lower the forks to ground; push lever to free position, switch off power, when parking on the slope, pull tight the brake apparatus and plug the wheels with wedge if the parking time is long
- (21) The protection valves on multiway valve and on steering device are already regulated, so the users shouldn't regulate randomly when using to prevent that the excessively high oil pressure leads to the damage of the whole hydraulic system and the burnout of the electric motor
- (22) Charge the tyres according to the pressure value stated in "tire pressure" indication
- (23) Treat the operation of non-load truck with additional apparatus as the operation load truck

5 Battery charging

- (1) In the first time of charging or boost charging of battery, act strictly according to the rules stated in battery specification
- (2) When the truck is in working, and when the battery voltage drops to 41V (72V) or any one of the cells voltage drops to 1.7V or the meter alarms, stop working immediately, charge the battery or change another fully charged battery
- (3) Inspect at any moment the density, the level and the temperature of electrolyte when charge the battery
- (4) Charge the battery at once after use of the truck, the storage period should be less than 24h; in order not to damage the battery, prevent under charging or over charging of the battery
- (5) In order to adjust the density of each cell, make a equalizing charge of the battery in regular service once a month, please refer to the related chapter to get the details of the charging method and usage maintenance

Chapter two The main performance parameters of forklift truck

I 、 The truck's outline dimension and performance parameters

1. The truck's outline dimension see figure 1-1




Figure 1-1 outline

2. Technical data

2.1 FE4D40-50 Technical data(Single wheel drive) (list 1-1)

Model number		FE4D40	FE4D45	FE4D50
specifications		SD	SD	SD
Drive mode:		Electromotion	Electromotion	Electromotion
Operation mode:		Seat-driving pattern	Seat-driving pattern	Seat-driving pattern
Rated capacity	Q(kg)	4000	4500	5000
Load center distance	C(mm)	500	500	500
Load distance	x(mm)	563	563	563
Wheelbase	y(mm)	1900	1900	1900
Service weight including battery	kg	6680	6950	7290
Axle loading,laden front/rear	kg	9420/1260	10210/1240	11060/1230
Axle loading,unladen front/rear	kg	3080/3600	3140/3810	3240/4050
Tyres size,front		250-15	250-15	250-15
Tyres size,rear		21X8-9	21X8-9	21X8-9
Track width,front	b ₁₀ (mm)	1200	1200	1200
Track width,rear	b ₁₁ (mm)	1040	1040	1040
Mask/fork carriage tilt forward/backward $\alpha/\beta(^{\circ})$		6/10	6/10	6/10
Lowered mast height	h ₁ (mm)	2260	2260	2260
Freelift height	h ₂ (mm)	150	150	150
Lift height	h ₃ (mm)	3000	3000	3000
Extended mast height	h ₄ (mm)	4117	4117	4117
Overhead load guard height	h ₆ (mm)	2265	2265	2265
Seat height	h ₇ (mm)	1200	1200	1200
Traction pin height	h ₁₀ (mm)	490	490	490
Overall length	l ₁ (mm)	3962	3962	3962
Length to face of forks	l ₂ (mm)	2892	2892	2892
Overall width	b ₁ (mm)	1450	1450	1450
Fork dimensions	s/e/l(mm)	50/150/1070	50/150/1070	50/150/1070
Fork carriage width	b ₃ (mm)	1380	1380	1380
Ground distance,centre of wheelbase m ₂ (mm)		165	165	165
Turning radius	Wa(mm)	2560	2560	2560
Travel speed,laden/unladen	km/h	14/15	13/14	13/14
Lift speed,laden/unladen	m/s	0.32/0.48	0.29/0.44	0.25/0.44
lowering speed,laden/unladen	m/s	0.40/0.35	0.42/0.35	0.45/0.35
Drawbar pull,laden/unladen S ₂ 5minute %		16/20	15/20	15/20
Drive motor rating S ₂ 60min	kw	16.6	16.6	16.6
lift motor rating S ₃ 15%	kw	13.5X2	13.5X2	13.5X2
battery voltage,nominal capacity v/A.h	K ₅	80/630	80/650	80/650
battery weight	kg	1740	1840	1840
working pressure of attachments MPa		14.5	14.5	14.5
oil volume for attachment	l/m	50	50	50

2.2 FE4D40-50 Technical data (Double wheel drive) (list 1-2)

Model number		FE4D40	FE4D45	FE4D50
specifications		DD	DD	DD
Drive mode:		Electromotion	Electromotion	Electromotion
Operation mode:		Seat-driving pattern	Seat-driving pattern	Seat-driving pattern
Rated capacity	Q(kg)	4000	4500	5000
Load center distance	C(mm)	500	500	500
Load distance	x(mm)	563	563	563
Wheelbase	y(mm)	1900	1900	1900
Service weight including battery	kg	6680	6950	7290
Axle loading,laden front/rear	kg	9420/1260	10210/1240	11060/1230
Axle loading,unladen front/rear	kg	3080/3600	3140/3810	3240/4050
Tyres size,front		250-15	250-15	250-15
Tyres size,rear		21X8-9	21X8-9	21X8-9
Track width,front	b ₁₀ (mm)	1200	1200	1200
Track width,rear	b ₁₁ (mm)	1040	1040	1040
Mask/fork carriage tilt forward/backward	$\alpha/\beta(^{\circ})$	6/10	6/10	6/10
Lowered mast height	h ₁ (mm)	2260	2260	2260
Freelift height	h ₂ (mm)	150	150	150
Lift height	h ₃ (mm)	3000	3000	3000
Extended mast height	h ₄ (mm)	4117	4117	4117
Overhead load guard height	h ₆ (mm)	2265	2265	2265
Seat height	h ₇ (mm)	1200	1200	1200
Traction pin height	h ₁₀ (mm)	490	490	490
Overall length	l ₁ (mm)	3962	3962	3962
Length to face of forks	l ₂ (mm)	2892	2892	2892
Overall width	b ₁ (mm)	1450	1450	1450
Fork dimensions	s/e/l(mm)	50/150/1070	50/150/1070	50/150/1070
Fork carriage width	b ₃ (mm)	1380	1380	1380
Ground distance,centre of wheelbase	m ₂ (mm)	165	165	165
Turning radius	Wa(mm)	2560	2560	2560
Travel speed,laden/unladen	km/h	14/15	13/14	13/14
Lift speed,laden/unladen	m/s	0.32/0.48	0.29/0.44	0.25/0.44
lowering speed,laden/unladen	m/s	0.40/0.35	0.42/0.35	0.45/0.35
Drawbar pull,laden/unladen S ₂ 5 minute %		16/20	15/20	15/20
Drive motor rating S ₂ 60min	kw	11X2	11X2	11X2
lift motor rating S ₃ 15%	kw	13.5X2	13.5X2	13.5X2
battery voltage,nominal capacity	K ₅ v/A.h	80/630	80/650	80/650
battery weight	kg	1740	1840	1840
working pressure of attachments	MPa	14.5	14.5	14.5
oil volume for attachment	l/m	50	50	50

II 、 The construction,principle and adjustment of the truck's main parts


1. Drive system :There are two configurations for the drive system: the front single-wheel drive and the front two-wheel drive.

1.1 Drive system(Single wheel drive)

1.1.1 Summarize

The drive system consists of gear box assembly, differential mechanism assembly and drive axle, the reducer drive gear connects directly to drive motor.The travel speed increases with the increment of rotational speed of drive motor, And when the rotational direction of the motor changes, the travel direction changes too.

1.1.2 Reducer casing and differential mechanism




Reducer,of which the two pairs of column screw gear make the rotational speed decline of the output axis of travel motor and make the twist moment rise from travel motor,and then send the twist moment to differential,lies between drive axle and travel motor,see figure 2-1

- | | | | |
|--------------------------|--------------------|-------------------|------------------|
| 1. differential assembly | 2. bolt | 3. locking plate | 4. bearing block |
| 5. bearing | 6. Adjusting pad | 7. O-ring | 8. bolt |
| 9. spring washer | 10. bearing cap | 11. grease seal | 12. bead flange |
| 13. taper bolt | 14. bearing | 15. bearing | 16. input axis |
| 17. bearing | 18. duplicate gear | 19. bearing | 20. paper washer |
| 21. tank cover | 22. bolt | 23. spring washer | 24. bolt |
| 25. stop dog | 26. bolt | 27. O-ring | 28. axle |
| 29. gear shaft | 30. box | | |

Figure 2-1 Reducer

Differential mechanism, of which the front connects to axle shell, is installed on the front-half shell by the bearing block in on two sides. The shell of the differential is left-right subdivision in construction, and there are two half axle gears and four planet gears in it. see figure 2-2




- | | | |
|-------------------|----------------------------|-------------------------------|
| 1. bearing | 2. bolt | 3. Right differential housing |
| 4. cushion ring | 5. half axle gear | 6. thrust washer |
| 7. epicyclic gear | 8. cross axle | 9. Gasket or washer |
| 10. nut | 11. Left differential case | 12. lock washer |
| 13. gear ring | 14. bolt | |

Figure 2-2 Differential mechanism

1.1.3 Drive axle

The drive axle consists of axle shell, wheel hub and arrester. It is installed in the front of framework

The shell is unit casted in construction, the tyres are fastened on wheel hub with studs and nuts, wheel hub is supported on axle shell by conical roller bearing, power is delivered by differential to differential axle by differential, wheel hub which drives front wheel to rotate is driven by differential axle. Differential shaft only bears the twisted moment delivered to wheel hub. There are seals inside left wheel hub to prevent water and dust or oil leakage installed in wheel hub. see figure 2-3



- | | | |
|--------------------------|----------------------------|--------------------------|
| 1. Half shaft bolt | 2. left half axle | 3. gland |
| 5. lockwasher 80 | 6. Bridge housing assembly | 7. breather plug |
| 4. nut M80X2 | 8. stop up | 9. Right half axis |
| 10. Right brake assembly | 11. hub nut | 12. Bolted post |
| 13. nut M20X1.5 | 14. gasket | 15. grease seal |
| 16. bearing | 17. wheel boss | 18. bearing |
| 19. oil seal collar | 20. oil seal | 21. brake drum |
| 22. Left brake assembly | 23. Brake hexagonal bolt | 24. Brake hexagonal bolt |

Figure 2-3 Drive axle

1.1.4 Installation of wheel hub

- (1) Fill the wheel hub with 100ml grease, and then fix it on the axle. see figure 2-4.
- (2) Screw up adjust nuts with 9.8N.m of twist moment, then reverse them 1/2 coil
- (3) Hang the weighter on the bolt to measure the starting moment of the wheel hub, when it reaches the defined value, start to screw up the nut.
starting moment: 49N·m—147N·m. (figure 2-5)




figure 2-4 injection of grease




figure 2-5 measurement of starting moment


(4) Install lock plate and lock nut, and cock up lock plate to stop nut

(5) Tyre assembly (figure 2-6)

Fix gas pole and nut cap upon tyre, and assemble wheel rib pay attention to the following items:

Attention:

- (a) Gas pole lies in the gap of the wheel rib
- (b) Wheel rib bolts should be installed toward outside



1.rim

2. tyre

figure 2-6 tyre assemble

1.1.5 Malfunction analysis

List 2-2 malfunction diagnose and adjustment

malfunction items	possible reason	adjusting method
shake a lot	the fastening bolts loosen	Tighten
Too high of oil temperature	gear oil deteriorates	replacing
	Un usual Oil level	Supplying or reducing
	Clamping stagnation of moving parts	adjustment
oil leak	Contacting surface bolts loose	tighten
	seal packing rings worn	replacing
noise	gear damages	replacing
	bearing damages	replacing


1.2 Transmission system(Double wheel drive)

1.2.1 Overview

The transmission system of forklift is composed of two reduction gearbox assembly and two travel motors. Driving gear of decelerator is connected directly with the travel motor, so the driving speed of forklift increases with the increase of motor speed and the driving direction can be changed by changing the direction of motor rotation.

1.2-1 Reduction gearbox assembly

Located at frame, One end of Transmission is linked with travel motor, the other end installation tire. See figure 2-1



1. Wheel hub	2. Wheel fixing screw	3. Needle cage	4. Shaft seal
5. Taper Roll. Bearing	6. Set-Right Spacer	7. Spacer	8. Breather plug
9. Socket head cap screw	10. Socket head cap screw	11. Socket head cap screw	12. Housing
13. Screw Plug	14. Magnetic Screw Plug	15. Locking pin	16. Needle cage
17. Taper Roll. Bearing	18. Retaining ring	19. Ring-gear carrier disc	20. Ring gear
21. Stud	22. Washer	23. Hexnut	24. Planet carrier
25. Retaining ring	26. Planet gear	27. Roller bearing	28. Retaining ring
29. Locknut	30. Retaining ring	31. Helix gear	32. Retaining ring
33. Ball bearing	34. Cover	35. Helix pinion	36. Ball bearing
37. Retaining ring	38. Retaining ring	39. Locking pin	40. Sun pinion
41. Feather key	42. Lever	43. Elastic pin	44. Pin
45. Socket head cap screw	46. Screw Plug	47. Cover	48. Seal
49. Washer	50. Connection	51. Bleeding valve cap	52. Bleeding valve
53. Basket	54. Basket	55. Piston	56. Elastic disc
57. Disk Pusher	58. Friction disk	59. Steel disk	60. Support disk
61. Retaining ring	62. Locking pin	63. Spring	64. Stud
65. Spring			

Figure 2-7 Decelerator

1.2.2 Care and maintenance

○,1 Before conducting running-in test of the gear box, users shall fill in gear oil (gear oil shall be selected in accordance with the instructions. Please refer to Table 2-1 for the specific requirements). Fill oil into the hole at top of the axle shell until oil is spilled out of the oil level hole in central axle.

○,2 It is necessary to check every 2000 working hours that the stroke of the brake piston is not over 3.5 mm, otherwise it is necessary to replace the brake disk to avoid accidents.

○,3 Check all the fasteners each 50 working hours . If any looseness is found, tighten it immediately.

○,4 Check the wheel axle and wheel hub connection each 50 working hours for any oil leakage. Re-apply sealant if any leakage is found.

○,5 Check if the oil level in the gear box meets standards. If the oil level reduces, users should promptly fill up

○,6 Oil in the gear box should be changed every 1000 working hours.

○,7 Annual technical maintenance: Disassemble the drive axle for inspection every year.

○,8 Check and debug requirements during the installation process:


2. Brake system

2.1 Summarize

Brake system,Being Two-front-wheel internal expansion oil pump type,consists of brake paddle,brake base pump and wheel brake staff

2.2 Brake paddle

The construction of brake paddle is illustrated in figure 2-7.The paddle transfers the stamp force exerted by the pushing rod of brake base pump into the pressure of brake oil



1. brake oil cup

2. brake support

3. brake sensor

4. bolt

5. brake pedal


6. brake pump

figure 2-7 brake paddle assembly

2.3 Brake base pump (figure 2-8)

Base pump consists of a valve support,a one-way-valve,a rebound spring and base leather cup,piston,assistant leather cup.The end of the base pump is fixed with lock washer and lock steel wire,And the outside of it is protected with rubber dust preventing cover.The base pump works under the assistance of pushing rod by operating brake paddle,Step down the brake paddle,the rod pushes the piston,the brake fluid flow back to oilcan through oil return hole until the base leather cup plugs the oil return hole.After the base leather cup push over the oil return hole,the brake fluid of the front cavity of base pump is compressed and open the one way valve and through brake pipeline flow into subsidiary pump.Then,the piston of each subsidiary pump pushes out to make the brake shoe wearing piece get contact with the brake drum,and finally stop the truck or make it slowdown. Now,the back cavity is supplied with the fluid by the brake fluid from oil return hole and oil-in hole.Release the brake paddle,the piston is push backward by the brake shoe rebound spring,at the same time,the brake fluid in each subsidiary brake pump is compressed by the rebound spring.Which makes the brake fluid flow back to base pump through one way valve,the piston returns back to initial position,the brake fluid in base pump flow back to oilcan through oil return hole,one way valve pressure is adjusted in proportion to the residual pressure in brake pipeline and subsidiary brake pump,the leather cups in subsidiary pump should be placed

correctly to prevent oil leaking and the case of air resistance which possibly occurs in emergency brake.




- | | | | |
|------------------|-------------------------|--------------------|----------------------|
| 1.latch nut | 2.pushing rod | 3.antidust cover | 4.locking steel wire |
| 5.locking washer | 6.assistant leather cup | 7.piston | 8.base leather cup |
| 9.spring | 10.cheak valve | 11.valve supporter | 12.pump body |

figure 2-8 base brake pump

2.4 Brake

The brake staff adopted is two shoe brake installed in the two sides of drive axle. The brake staff consists of two groups of brake shoes, subsidiary brake pumps and regulators, one end of the brake shoe, which holds back the parking brake parts through rebound spring and Pressure spring, contacts with fixing pin and another end of it contacts with regulator. In addition, there are brake packing device and automatic regulating device assembled on brake staff. See figure 2-9



- | | | | |
|----------------------------|-------------------------|---------------------------|--------------------|
| 1.brake baseplate assembly | 2.clearance adjuster | 3.friction plate assembly | 4.washer |
| 5.pull rod | 6. spring | 7.washer | 8.push rod |
| 9. spring | 10.push rod | 11.spring | 12.adjusting lever |
| 13. spring seat | 14. spring | 15. spring cap | 16. spring |
| 17. spring seat | 18.pull rod | 19.pin | 20. washer |
| 21.rubber plug | 22.brake cable assembly | 23.bolt M8×16 | 24.washer 8 |
| 25.cylinder | 26. protective cover | 27.piston rod | 28.piston |
| 29.ceal cup | 30.spring | 31.oil plug | 32.screw |

33. protective cover 34. dust cover
 figure 2-9 brake stuff

(1) Motion of brake stuff

The brake drum is pressed by the leading brake shoe and the secondary brake shoe with the same force from subsidiary brake pump, when the top side of the brake shoe is stopped by the fixed pin, the brake shoe will move toward brake drum until being stopped by the fixed pin, then the friction between wearing piece and brake drum will increase. As the pressure the leading brake shoe exerted on the secondary brake shoe is much larger than the subsidiary pump pressure. There will occur a quite large brake force. see figure 2-10

When driving backward, the brake stuff works in reverse to it when drives forward. see figure 2-11




figure 2-10 motion when driving forward





figure 2-11 motion when driving backward

(2) parking brake

The parking brake device which consists of pulling rod and pushing rod is assembled in wheel brake stuff. The pulling rod, of which the action is transported to the side of secondary brake shoe, is installed on the side of leading brake shoe. See figure 2-12


(3) gap-self-regulating device

Gap-self-regulating device can keep a proper gap between wearing piece and brake drum, it works only when driving backward. see figure 2-13.



1. pin 2. pull rod 3. active hoof
 4. driven hoof 5. jackstay

figure 2-12 parking brake



1. adjusting mechanism 2. spring 3. dragline
 4. guide slot 5. pull rod

figure 2-13 gap-self-regulating device

(4) Motion of gap-self-regulating device

Brake the truck when driving backward, the secondary brake shoe gets contact to and roll together with the leading brake shoe, making pulling rod rotating rightward around point A, see figure 2-13, and B point rises. After the release of brake, pulling rod turns left under the force of spring, B point descending. with the increasing of the gap between wearing piece and brake

drum, the vertical distance of B point rotating grows, and the regulating device moves one tooth space, then, regulating rod gets longer (see figure 2-14) the gap narrows, regulating gap lies between 0.4mm and 0.45mm.

2.5 Parking brake operating device (figure 2-15)

Parking brake handle is cam in pattern. Adjuster lying at the end of handle is available to adjust the brake force.

Turning the adjuster clockwise, the brake force increases; Turning the adjuster counter clockwise, the brake force decreases.

Pulling force: 196N ~ 294N




figure 2-14 gap-self-regulating device




figure 2-15 parking brake handle

2.6 Gist of dismantlement and regulating for brake staff

Instruction of decomposing, assembling, regulating and brake paddle adjusting method when the wheel and hub is disassembled.

2.6.1 The decomposing of brake device

(1) Disassemble supporting pin, adjusting rod, regulating device and spring on the brake shoe. See figure 2-16

(2) Disassemble the the reverse spring on brake shoe. See figure 2-17





figure 2-16

(3) Disassemble the fixed spring on leading brake shoe. See figure 2-18

(4) Disassemble the leading brake shoe and secondary brake shoe. Then disassemble the regulator and regulating spring. See figure 2-19




figure 2-18




figure 2-19

(5) Disassemble the brake tube from the driven brake pump, and disassemble the assembling bolts on the subsidiary brake pump. Then disassemble the subsidiary brake pump from brake device motherboard. See figure 2-20

(6) Disassemble the E baffle ring to fast the brake dragline from brake device motherboard. Then disassemble brake device motherboard bolts, and disassemble brake device motherboard from drive axle. See figure 2-21




figure 2-20




figure 2-21

(7) Analyze subsidiary brake pump: Disassemble scraper seal. Press one terminal piston to push out another terminal one, then push out the rest one with finger. See figure 2-22





figure 2-22

2.6.2 Brake device inspection

Inspection of parts. Repair and replacement of Damaged parts

(1) Check up if there is any rust of inner surface of sub-pump and outside of piston; then measure the clearance between piston and pump body. Standard size: 0.03mm—0.10mm; limit size: 0.15mm

(2) Visually Check up if there is any damage and deformation of cup leather, please replace if abnormal.

(3) Measure the free length of brake sub-pump, if abnormal, please replace.

(4) Measure the thickness of friction slice, if exceed the limit wear, please replace. Standard: 8.0mm; limit: 2.0mm. See figure 2-23.

(5) Eye-measure if there is any damage on inner surface of brake drum, if abnormal, amend by lapping. If exceed amendment limit, please replace. Standard: 314mm; limit: 316mm. see figure 2-24




figure 2-23




figure 2-24

2.6.3 Assembling brake device

(1) Wipe brake liquid on cup leather and piston of brake sub-pump, assembling spring, piston cup leather, piston and defend ring.

(2) Install brake sub-pump on motherboard.

(3) Mount motherboard on drive axle.

(4) Wipe anti-heat lubricate grease on the region instructed in figure 2-25.

Pay attention not to wipe on wearing piece.

(a) Interface between motherboard and brake hoof

(b) Fasting pin;

(c) Interface between hoof slice and press spring base;

(d) Hand brake pull rod pin;

(e) Adjust bolt and rotating devices.

(5) Block parking brake wire rope by E-shape retainer ring.

(6) Fix brake shoe hoof by fastness spring. See figure 2-26.

(7) Put compress spring on hand brake handspike, hen fix handspike on brake hoof. See figure 2-27




figure 2-25




figure 2-26



figure 2-27

(8) Fix guide of brake shoe on brace pin, then fix rebound spring of brake hoof. Install main shoe first, then sub-shoe. See figure 2-28

(9) Fit adjustor, spring, ejector pin, rebound spring. Please notice as follow:

(a) The screw thread direction of regulator and its installation;

(b) The direction of spring of adjustor(no contacting spring with tooth of adjustor)

(c) The direction of rebound spring of ejector pin(spring hook of brace pin shall rivet on side of ejector pin relatively)

(d) The end of adjusting lever must contact with adjustor tooth.

(10) Connect brake oil pipe to sub-pump

(11) Measure inner diameter of brake drum and outer diameter of brake shoe, regulate adjustor, make the difference subtracting inner diameter from outer diameter equals 0.3mm-0.5mm. See figure 2-29




figure 2-28




figure 2-29

2.6.4 Operating trial for self-adjustor of clearance See figure 2-30

(1) Adjust diameter of brake hoof close to the regulation size first, rotate adjustor by pulling adjusting bar, when releasing hand, adjusting bar return original place but adjustor gear doesn't rotate.

Notice: Even if when releasing hand, adjustor gear and adjusting bar return together, the adjustor can still work normally.

(2) Please examine as follow if adjustor can't act as introduced when pulling adjusting bar.

(a) Ensure adjusting bar, ejector pin, ejector pin spring and spring are all fixed.

(b) Check rebound spring of ejector pin and spring of adjustor, check adjuster gear for running state and whether there is over wearing in mating surface. check if there is touching between lever and gear. Replace damage parts.




figure 2-30

2.7 Adjusting for Brake pedal See figure 2-31(a)

(1) Shorting handspike

(2) Adjusting limit screw of pedal to make optimum height of pedal. See figure 2-31;

(3) Stretch handspike until the front end of handspike touch the piston ,then, unthread for 1 or 2 circle to make the free journey among 10mm-20mm.

(4) Tighten handspike nut and limit nut of pedal




figure 2-31

(5) Adjusting brake switch as figure 2-32

- (a) After adjusting brake pedal height, release lock nut of brake switch
- (b) Pull off plug to separate wire
- (c) Rotate switch to make clearance into A=1mm
- (d) To be sure when step pedal down, the light of brake shall be open.
- (e) Tighten the nut.




figure 2-32 braking light button

2.8 Malfunction and cause See List 2-3

List 2-3

Malfunction	Cause	Elimination
	1 Brake system leakage	Repair
	2 Clearance of brake hoof is not ok	Regulate adjustor
	3 Brake is too hot	Check if skid

Brake badness	4 Mal-touching between brake drum and friction slice	Adjusting again
	5 Dirt on friction slice	Repair or replace
	6 Impurity is in liquid	Check brake liquid
	7 Bad-regulate for brake pedal(inching valve)	Regulate
Noise of brake	1 Friction slice impurity or case hardening	Repair or replace
	2 Motherboard deformation or bolt loose	Repair or replace
	3 Hoof flake deformation or mal-installation	Repair or replace
	4 Friction slice abrasion	Replace
	5 Wheel bearing loose	Repair or replace
Brake unbalanced	1 Oil dirty on friction slice	Repair or replace
	2 Brake hoof clearance is not very good	Regulate adjustor
	3 Sub-pump lose function	Repair or replace
	4 Brake hoof rebound spring failure	Replace
	5 Brake drum deflexion	Repair or replace
Brake force weak	1 Brake system leakage	Repair or replace
	2 Clearance of brake hoof is not ok	Regulate adjustor
	3 Air in brake system	Deflate air
	4 Brake pedal adjusting is not ok	Adjusting again

2.9 Maintenance

① Before running trial of new axle you have to infuse gear oil. Fill oil into filler well located on top of axle shell until oil spill over fuel level hole located on middle of axle shell.

② The thick of friction slice of brake hoof is 8mm normally, can not be less than 2mm. Check it once a month, if the thickness is less than 2mm, replace it immediately to avoid any accident.

③ Technical maintenance every 50 hours:

(a) After the axle has worked 50h of together with the truck,replace the gear oil,Cleaning axle shell inner cavity thoroughly before replace by new gear oil

(b) Check tightness of bolt and nut,if loose, tighten it immediately.

(c) Check if there is leakage of connection of wheel hub and differential shaft, if necessary, recoat airproof glue again.

④ Technical maintenance every working month:

- (a) Check brake drum to see whether there is destructive abrasion.
 - (b) Check brake shoe for abrasion,if it can not reach the operating requirement,replace the brake shoe at once.
 - (c) Check whether the axle shell is normal,if the oil level is less than normal,supplement the oil
- ⑤ Technical maintenance semiannually replace gear oil of axle shell once every a half year
 - ⑥ Technical maintenance yearly Disassembly checkonce a year.
 - ⑦ Check and debug requirement during installation

When renew drive axle wheel hub,becareful for regulating adjustor to make optimum clearance between brake drum and friction slice equals 0.3mm~0.5mm. Infuse 100ml 3# lithium-base lubricate greese into taper roller bearing of wheel hub.

Adjusting for clearance of wheel hub: Tighten lock nut until brake drum of wheel hub can only rotate slightly. Then reverse lock nut 1/8 circle, at this time, the brake drum can rotate freely without seizing-up, also without axial motion and deflexion. Now you can place retainer washer and tighten lock nut.

3. Steering system

3.1 Summary

Steering system (see figure 2-33) consists mainly of steering wheel,steering shaft,steering device,steering oil pump and steering axle and so on. Steering shaft connects to steering device by universal joint. connecting shaft connects,with universal joint,to steering wheel. the steering limp can tilt forward and backward to a proper position. steering axle,installed on the tailbracket of the rear of the framework,has a kunckle on both left and right side. Kunckle is pulled by steering oil cylinder through connecting rod,which makes steering wheel to turn and achieves turning.





figure 2-33 Steering operation device

3.2 Full Hydraulic cycloid redirector

Full Hydraulic redirector(figure 2-34) can transfer pressure liquid from pump to oil cylinder according to rotatory angle of steering wheel. When hydraulic system failure, steering operation can be done by manpower.

The redirector consists of a normal redirector and a assembled valve, there is a safety valve which located in the hole of top cover of assembled valve, also there is a two-way overloading

valve in valve body to be used to prevent damage on equipment when hydraulic pressure is too high produced by impact of outside force which is from ground to wheels during travelling. Both safety valve and two-way overloading valve are regulated in optimum by manufacturer, so, users shall not regulate it randomly.




- | | | |
|--------------|---------------------------|----------------|
| 1 Limit pin | 4 Universal driving shaft | 7 Rotor |
| 2 Valve body | 5 Spring slice | 8 Stator |
| 3 valve core | 6 Joint piece | 9 Valve pocket |

figure 2-34 Hydraulic cycloid redirector

3.3 Steering axle

Steering axle is box-cross-section welding in pattern. It consists of the parts as steering axle body, steering cylinder, connecting rod, steering knob, steering wheel and so on. Steering trapezium is crank block in construction that the cylinder piston rod, by connecting rod, makes the kunckle steer, further, steering wheel deviate to achieve turning. steering axle located, by rear and front pin, upon fixing board which is fasted by bolts on the tail bracket of rear part of framework, which makes it possible for the axle body to sway around the pin rod. there are kunckles on each side of steering axle. Rear wheel hub is assembled by two conical roller bearings on steering knob axes. wheels are fastened on wheel hub by wheel frame. there are oil seals installed inside of the bearings to make the lubricating grease stay in the cavity of kunckle.




- | | | |
|----------------------------|------------------------|----------------------|
| 1. Left knuckle assembly | 2. Left main pin | 3. Steering bridge |
| 4. spring washer | 5. bolt | 6. adjusting shim |
| 7. adjusting shim | 8. adjusting shim | 9. grease cup |
| 10. Rear axle support | 11. Steel back bushing | 12. Shaft end baffle |
| 13. spring washer | 14. bolt | 15. close over |
| 16. bearing | 17. adjusting shim | 18. bearing |
| 19. Right knuckle assembly | 20. nut | 21. spring washer |
| 22. screw | 23. Lip seal ring | 24. bearing |
| 25. hub | 26. bearing | 27. nut |
| 28. lockwasher | 29. wheel hub cover | 30. Hub nut |
| 31. hub bolt | 32. cushion ring | 33. gasket ring |
| 34. Right main pin | 35. grease cup | 36. link pin |
| 37. bush | 38. bearing | 39. connecting rod |
| 40. Shaft ring | 41. Steering cylinder | |

figure 2-35 steering axle

(1) Kunckle


Kunckle,combined by kunckle king pin,conical roller bearing,anti-dust cover,O ring,locates between upper and down side of the steering axle body terminals. the upper end of king pin is fastened on axle body by stop pin,and the lower end of it is fasten on axle body by forelock. The supporter is supported by conical roller bearing which is pressed-in the axle body. (see figure 2-36)



- | | | |
|----------------|-------------|-------------------|
| 1. close over | 2. bearing | 3. adjusting shim |
| 4. bearing | 5. knuckle | 6. gasket |
| 7. gasket ring | 8. king pin | |
- figure 2-36

(2) Steering cylinder

Steering cylinder designed as a double-acting piston in pattern,that is,the piston rod connects on each end to kunckle with connecting rod,and the pressure from fully hydraulic steering device makes,by steering cylinder,piston rod move left and right to achieve left and right turning. the piston seal adops the combination of supporting ring and O ring. there is Yx ring locates between cylincer cover and piston rod to keep their leak-proofness. The oil cylinder is fixed upon steering axle by cylinder covers on two sides. (see figure 2-37)



- | | | |
|----------------|------------------------------|---------------------------|
| 1. piston rod | 2. cylinder cover | 3. scraper seal |
| 4. Zocany ring | 5. Guide ring for piston rod | 6. bead flange |
| 7. O-ring | 8. cylinder block | 9. T-type Turconger loop |
| 10. O-ring | 11. Guide ring for piston | 12. Guide ring for piston |
| 13. plunger | 14. steel ball | |

figure 2-37 steering cylinder

(3) Wheel hub

Wheel Hub is fitted on kunckle by taper bearing, wheel is fitted on wheel hub by wheel rim, there is oil seal inside of bearing to keep lubricate greese in cavity of wheel hub and kunckle. There is nut to adjust bearing for elasticity.

3.4 Gist for adjustment and maintenance

(1) See figure 2-38, lubricate inner cavity of wheel hub, inside or outside bearing and cover of wheel hub, meanwhile, lubricate oil seal

(2) Fit bearing outer ring on wheel hub and fit wheel hub on kunckle shaft.

(3) Fit washer and tighten castle nut, its tightening torque is 206-235N.m(21-24kgm),then loose castle nut, tightening nut again, at this time, the torque is 9.8N.m(1kgm)

(4) Tap wheel hub gently by wood hammer and rotate wheel hub 3-4 circle to ensure there is no loose of wheel hub.

(5) Tighten castle nut and make slot aim at split pin hole of kunckle

(6) Tap wheel hub gently by wood hammer again, rotate wheel hub 3-4 circle by hand to ensure rotation stability, and measure rotation torque to ensure it between 2.94-7.8N. m(0.3-0.8kgm)

(7): If rotation torque is more than standard value, you can untread 1 / 6 circle and then measure rotation torque again.

(8) After rotation torque is regulated at its standard value, lock castle nut by split pin




figure 2-38 Adjustment for pretightening force

3.5 Inspection after rebuilding of steering system

(1) Run steering wheel right and left to its end to check if its running is uniformity and stability

(2) Check up laying out of hydraulic pipeline and direction changing for mislaying

Jack rear wheel up, running steering wheel right and left slowly, repeating several times, exhaust air out of hydraulic pipeline and oil cylinder

3.6 Diagnose of steering system (list2-4)

List 2-4

problem	cause	elimination
steering wheel can not move	damage or malfunction of oil pump	replace
	hose connector is damaged or plug of pipeline	replace or cleaning
steering wheel dullness	safety valve pressure is too low	adjust pressure
	air in oil circuit	exhaust air
	failure of steering reset. Rivet spring slice broken or elasticity is not enough.	replace spring slice
	too big inside leakage of steering cylinder	check piston seal
Forklift S-route travel or sway	broken of spring or no elasticity	replace
too big noise	oil level in oil box is low	fuel
	plug of inhale pipe or filter	cleaning or replacing
oil leakage	damage of guide bush seal for steering cylinder or damage of pipeline or damage of connector	replace


4. Electrical system

Electrical system of FE4P40-50N is powered by 80V battery set .traction power of the truck is powered by AC motor, lifting power is produced when AC motor is driving the oil pump to produce oil pressure. Lighting system is powered by battery 80V to 24V voltage.


4.1 Electronic control assembly (Inmotion)

The Inmotion controller of ACS AC controller in the Inmotion group, the type of controller of high security, reliability, flexibility, convenient operation and a body, through the advanced control software to ensure the motor in different modes, running smoothly, including regenerative braking speed and large torque condition, zero speed and torque control input / output port and proprietary software, ensure the controller for the economy and efficiency of electromagnetic brake and hydraulic control system.

Traction controller (Single wheel drive)




Pump controller (Double pump)




(Figure 4-7)

Traction controller (double wheel drive)




Pump controller (Double pump)




(Figure 4-8)

Forklift traction AC frequency conversion motor, steering AC frequency conversion motor controller, dashboard display. Ac drivers are the world's leading suppliers of electric vehicle systems under the Zapi Group products. The selection of AC frequency conversion motor efficient durable and basically maintenance-free. Because it does not have a DC motor commutator (the commutator limits the acceleration of the vehicle, especially when the vehicle is moving at high speed and also limits the braking torque). The controller is a general controller for electric vehicles that communicates with the CANopen protocol through its analog and digital I / O and communication devices. Very suitable for managing forklift motion I / O, operation control and information display, it can carry out battery discharge monitoring, with a variety of protection functions. Dashboard display can be used for a variety of data display. Can be factory or user settings, can enter user commands and other functions.

4.1.1 Electrical principle chate



(Figure4-8.1 Single wheel drive and double pump)



(Figure4-8.1 Double wheel drive and double pump)

4.1.2 Main functions and settings

By correctly setting the motor's technical parameters and control technology parameters and function values of the controller, the electric forklift's safety and high efficiency performance and complete operation function can be realized.

- 1, advanced design and production process to ensure the best quality and reliability.
- 2, a powerful ARM core processor and operating system, while meeting functional tasks and motor control requirements.
- 3, reverse braking and regenerative braking. In the vehicle, when the steering rod reverse, reverse braking signal is generated, it through the motor drive control of traction motor is given a braking torque, in order to achieve the purpose of deceleration of the vehicle. The braking force is controlled by the accelerator pedal. Regenerative braking is the relative speed of vehicle higher traction motor speed conditions produced by the control of the controller, the braking energy can be converted into electrical energy back to the battery. Especially the electric forklift on the ramp down sliding slope, in order to properly reduce the vehicle speed to slip down slope, through appropriate lifting the accelerator pedal, achieve regeneration a brake, extending the battery charging mileage.
- 4, the ramp function. The backward slip preventing electric forklift AC traction motor has excellent function decline on the ramp.
5. The maximum speed of electric forklift can be adjusted. The reasonable setting of the maximum speed of electric forklift can prevent overloading of traction motor due to excessive speed.
- 6, static return off. If seat switch or key switch is disconnected, the control device is turned off. The direction control rod must be brought back into the middle space to restart. If the driver leaves the vehicle and returns at any time. This function prevents unexpected unsafe operations from occurring. There is a time delay of several seconds at the input end of the seat switch. To allow the seat switch to be temporarily disconnected in the event of a jolt.
7. Safety protection function. If the power component of the controller is damaged in operation, the controller will disconnect the main contactor in the shortest time; When the temperature rise of the controller is too high, the controller will automatically limit the armature current of the motor. When the battery voltage is too low, the controller stops working for safety.
8. The traction motor controller and the oil pump motor controller both have the function of self-diagnosis. In the process of operation, the controller will display the fault code on the display instrument once it has a fault, and automatically make the controller stop working. To ensure the security of the operating system.
- 9, display meter will show battery power and accumulative hours of work and remote vehicle management mode.

4.1.3 Maintenance of Circuit system

- (1) Check contact wear condition; replace contact when it has worn. Contact contact should be checked once every 3 months.
- (2) Check pedal or handle fretting switch; measure voltage drop at both ends of fretting switch, no resistance when fretting and closing, clear sound when released. Check every 3 months.
- (3) Check main circuit: battery-controller-motor connection cable. Ensure cable insulation is good and circuit connection fastens. Check every three months.
- (4) Check the mechanical movement of the pedal. See if the spring can deform normally, and whether the potentiometer spring can reach the maximum level or set level. Check every three months.
- (5) Check the mechanical movement of the contactor; should move freely and without adhesion, the mechanical movement of the contactor should be checked every 3 months.

4.1.4 Combination Instrument

IDD is a vehicle-mounted instrument based on CAN and wireless communication, which can display vehicle speed, working time, battery power, Chinese and English display, password












protection, fault code and other information. At the same time, it can realize remote voice alarm and scheduling, vehicle positioning, remote locking, remote help and other industrial Internet functions. It can also modify the configuration parameters according to users, and provide online real-time communication. Cloud data storage and background monitoring service. IDD has the advantages of instant communication, accurate positioning, high visualization and so on. It is the best terminal for future Internet of things and cloud service of electric forklift. Widely used in all kinds of industrial electric vehicles.



(Figure4-6) IDD Instrument

No.	Parameter name	Adjectival Description
①	hourmeter	The figure shows the current accumulated working time of the vehicle 5 digits display; After the key switch is connected to the power supply vehicle, the working timer starts to work;
②	Wheel angle indication	The arrow represents the direction of the steering wheel;
③	Working mode indication	Display the current mode of work, "S (tortoise speed)", "P", "E" 3 working mode
④	Speed display	Display current vehicle speed, unit KM/h or MPH, (shortcut key 4 switching unit)
⑤	Battery Life	Displays the current battery power icon, 10 cells, and the battery power comparison table 1.5.1
⑥	Real - time day of day	Display real-time of the day: time-minutes-seconds
⑦	MicroSD card indication	Display this icon when there is a MicroSD card in the instrument
⑧	GPRS signal indication	Display this icon when the meter communicates normally with the carrier base station
⑨	WiFi signal indication	This icon is displayed when WiFi is working properly in the instrument
⑩	GPS signal indication	This icon is displayed when the instrument receives valid positioning data
⑪	Walking speed display	Same as 4
⑫	Cumulative driving time	Shows the cumulative driving time of the vehicle, unit h
⑬	Traction working time	Displays the time for the towing ACS to work , unit h
⑭	Working time of pump	Show pump ACS working time, unit h

Keyboard Shortcuts

Icon	Name	Function
	Upward	Move the cursor up, or add 1 selected numbers up and up. Main interface down - cut high contrast
	Left	Move the cursor left
	Right	Move the cursor to the right
	Down	Move the cursor up, or subtract the selected number by 1 Lowering contrast under main Interface
	Cancel	Cancel the current content or return to the higher menu
	Enter	Confirm the current operation and enter menu mode under the main interface
 ~ 	Number	Modify the number of the selected cursor
	Number 2	Switch to mode at main interface "S、P、E"
	Number 3	Switching between the main interface and the secondary interface
	Number 4	Speed unit KM/h and MPH unit switching

4.1.5 Fault analysis

ACS Controller fault table and diagnostics guide

Code display on the programmer	Code display on the instrument	Troubleshoot	Fault cause
1	20	Incorrect start Accelerator pedal switch active before key on	Release pedal switch
2	21	Incorrect start Forward switch or reverse switch active before key on	Turn off the direction switch
3	22	Forward switch and reverse switch active at the same time	Direction switch fault
4	23	Throttle analog value out of range	Throttle fault or analog need to be calibrated

5	24	Throttle analog fault	
6	31	Traction controller CAN communication fault	Check CAN wire of controller and display
7	32	Battery voltage low	Need charge
8	34	CPU fault	Reset key
9	36	Incorrect start Tilt switch active before key on	Reset tilt switch
10	37	Incorrect start Side switch active before key on	Reset side switch
11	38	Incorrect start Attachment switch active before key on	Reset attachment switch
12	39	Incorrect start Tilt switch active before key on	Reset tilt switch
13	40	Lift analog value out of range	Lift analog fault or need to be calibrated
14	43	Steer analog value out of range	Steer analog fault or need to be calibrated
15	44	Traction controller speed protection	Vehicle speed is too high alarm ”
16	45	Traction controller encoder fault	1、 Traction controller encoder fault 2、 Traction motor speed sensor connection wire is open
17	81	Traction controller temperature is low	Traction controller temperature is low alarm
18	82	Traction controller temperature is high	Traction controller temperature is high alarm
19	83	Traction controller temperature sensor fault	Traction controller temperature sensor fault
20	84	Traction motor temperature is low	1、 Traction motor temperature is low 2、 Traction motor temperature sensor is fault
21	85	Traction motor temperature is high	1、 Traction motor temperature is high 2、 Traction motor temperature sensor is fault
22	86	Traction motor temperature sensor fault	1、 Traction motor temperature sensor is fault 2、 Traction motor temperature sensor connection wire is open
23	87	Traction motor encoder fault	1、 Traction motor encoder fault 2、 Traction motor speed sensor connection wire is open

24	88	DC bus voltage of traction controller is high	1、 DC bus voltage high 2、 The ramp is too steep
25	89	DC bus voltage of traction controller is low	Need to charge or check power wiring
26	90	The default value of the traction controller is updated	Reset key
27	91	Traction drive limit	Battery low vehicle speed limit
28	97	Open drain of traction output open or short	Check the wire of open drain of traction output open or short
29	98	Traction controller over current or short	Check power wiring
30	101	Traction controller short	1、 Check power wiring 2、 Controller enable before contactor pull
31	102	Traction controller temperature is high cut back	Traction controller temperature is high need cool
32	103	Traction motor temperature is high cut back	1、 Traction motor temperature is high need cool 2、 Traction motor temperature sensor fault
33	104	Traction controller over current	1、 Vehicle overload or Mechanical clamping 2、 Traction motor speed sensor fault
34	105	Traction controller precharge failed	Replace the pre charge resistance
35	110	DC bus voltage of traction controller is low cut back	Battery need charge
36	111	DC bus voltage of traction controller is high cut back	DC bus voltage of traction controller is high cut back
37	112	DC bus voltage of traction controller is high cut back(Hardware monitoring)	DC bus voltage of traction controller is high cut back(Hardware monitoring)
38	114	Internal power supply error	Traction motor temperature sensor or speed sensor connection wire is open
39	121	Pump controller temperature is low	Pump controller temperature is low alarm
40	122	Pump controller temperature is high	Pump controller temperature is high
41	123	Pump controller temperature sensor fault	Pump controller temperature sensor fault
42	124	Pump motor temperature is low	1、 Pump motor temperature is low 2、 Pump motor temperature sensor fault
43	125	Pump motor temperature is high	1、 Pump motor temperature is high 2、 Pump motor temperature sensor fault

44	126	Pump motor temperature sensor fault	1、 Pump motor temperature sensor fault 2、 Pump motor temperature sensor connection wire is open
45	127	Pump controller encoder fault	1、 Pump motor speed sensor fault 2、 Pump motor speed sensor connection wire is open
46	128	DC bus voltage of pump controller is high	DC bus voltage of pump controller is high
47	129	DC bus voltage of pump controller is low	Check power wiring
48	130	The default value of the pump controller is updated	Reset key
49	132	Pump drive limit	Battery voltage low need charge
50	137	Open drain of pump output open or short	Check the wire of open drain of pump output open or short
51	138	Pump controller over current or short	Check power wiring
52	141	Pump controller short	
53	142	Pump controller temperature is high cut back	
54	143	Pump motor temperature is high cut back	Pump motor temperature is high alarm
55	144	Pump controller current calibration error	Reset key
56	145	Pump controller precharge failed	Replace the pre charge resistance
57	150	DC bus voltage of pump controller is low cut back	DC bus voltage of pump controller is low cut back
58	151	DC bus voltage of pump controller is high cut back	DC bus voltage of pump controller is high cut back
59	152	DC bus voltage of pump controller is high cut back(Hardware monitoring)	DC bus voltage of pump controller is high cut back(Hardware monitoring)
60	153	Pump controller CPU fault	Reset key
61	154	Pump controller speed control fault	Pump controller speed control fault
62	157	BMS over temperature protection	BMS over temperature protection
63	158	BMS single body over discharge	BMS single body over discharge need charge
64	159	BMS over voltage protection	BMS over voltage protection
65	163	BMS over current	BMS over current

66	164	Charge protection	Charge protection
67	156	Temperature protection	Temperature protection
68	155	BMS CAN bus off	BMS CAN bus off
69	165	Seat switch off after a period of time, the direction of the request to reset	Reset direction switch
70	168	BMS indicates Limit Current alarm	BMS indicates Limit Current alarm
71	169	BMS indicates cutoff Current alarm	BMS indicates cutoff Current alarm
72	170	BMS indicates brake Current alarm	BMS indicates brake Current alarm
73	171	BMS CAN Error	BMS CAN Error
74	13	HPG CONTROLLER EEPROM KO	Reset key
75	30	HPG CONTROLLER BATTERY VOLTAGE LOW	HPG CONTROLLER BATTERY VOLTAGE LOW NEED CHARGE
76	33	DC MOTOR VOLTAGE HIGH	RESET KEY
77	49	DC MOTOR OPERATING CURRENT IS ZERO	HPG CONRTOLLER SENSOR FAULT
78	53	HPG CONRTOLLER OVER CURRENT	HPG CONRTOLLER OVER CURRENT
79	62	HPG CONTROLLER TEMPERATURE HIGH	HPG CONTROLLER TEMPERATURE HIGH NEED COOL
80	66	HPG CONTROLLER BATTERY LOW	HPG CONTROLLER BATTERY LOW NEED CHARGE
81	74	HPG CONTROLLER DRIVER SHORTED	HPG CONTROLLER DRIVER SHORTED
82	76	HPG CONTROLLER COIL SHORTED	HPG CONTROLLER COIL SHORTED
83	78	HPG CONTROLLER VACC NOT OK	HPG CONTROLLER VACC NOT OK
84	79	HPG CONTROLLER INCORRECT START	HPG CONTROLLER INCORRECT START
85	241	HPG CONTROLLER CAN BUS KO	CHECK CAN WIRE OPEN AND CAN SPEED RATE
86	242	HPG CONTROLLER BATTERY OVER VOLTAGE	HPG CONTROLLER BATTERY OVER VOLTAGE
87	243	KEYOFF SHORTED	Key switch adhesion (HPG DC pump control fault)
88	244	HPG CONTROLLER WATCHDOG ERROR	HPG CONTROLLER WATCHDOG ERROR

89	246	HPG CONTROLLER WAITING FOR MAIN CONTACTOR	TURN OFF THE PUMP CONTACTOR PARAMETER
90	161	DISPLAY CAN FAULT	CHECK DISPLAY AND CONTROLLER CAN CONNECTION

5. Battery

Battery framework see figure 2-45.




figure2-45 battery

5.1 Battery safety requirements

△ Good ventilation is necessary. Because hydrogen and oxygen take place at the later period of charging battery, so, sparks will lead to explosion.

△ There is acid mist taking place during charging, please exhaust it and cleaning battery and workplace immediately after charging.

△ The man who operate the battery should be performed in overall and protection goggles. In case that acid solution touches clothes, wash it immediately with plenty of water. If the skin or eye touch the electrolyte (acid solution), you should be not only washing with plenty water but also going to hospital immediately. The acid extravasations should be eliminated through neutralization treatment.

△ For the avoidance from the injury of acid fluid, Do not operate battery if you are unfamiliar to its usage and risk

△ Do not place any metal object or tool on battery to avoid short-circuit.

△ Only after cutting off power entirely can you disconnect the connection of battery to power source. no plugging or unplugging of linker with power.

△ Before installation, please read operation instruction manual carefully. keep the manual with you after reading, so as to get convenience of it at any time.

5.2 Battery use requirements

The lifespan of battery is between 2~3 years. if use and maintenance are proper, its lifespan can be more than 4 years. it will be damaged within several months under unsuitable usage.

Check electrolyte level regularly, recharge and inspect battery in time. It is easy for battery maintenance but you should be patient and careful. Enough and standard density of electrolyte, keeping battery and its terminals cleanliness are necessary for longevity of battery.

Check if there is standing water in battery box, once find it, absorb it immediately.

In addition, Do not keep battery with electrolyte. When storing used battery with full capacity in short time, please charge it once per month to compensate self-discharging and to prevent or eliminate pole piece of battery sulfuration.

If battery can not be fully charged then fully discharged during working time, do it once a month, which can keep battery normal capacity and prevent its polar plate from sulfating.

keep battery exterior clean

Check battery and its fasting state of outgoing traverse clips.

Check battery shell for traverse cracking and damage, check pole and outgoing traverse clips for burning out.

Rub-up dust of battery by cloth, if there is electrolyte stains, rub-up or cleanse by hot water, then dry it by cloth. Clean dirt and oxide of pole, rub-up lead and lead clip. Dredge venthole of oil inlet. Apply a thin industrial Vaseline on pole and lead clip.

Check battery for liquid level.

Insert a glass pipe which is 6~8mm inner dia. and 150mm length into oil inlet vertically until touching top surface of pole piece, then cover top mouth of pipe by thumb and nip pipe out of oil inlet by index finger, middle finger and ring finger, the liquid level of the glass pipe equals the liquid level of battery which is higher than pole slice, it is about 15-25mm. Finally, put electrolyte of pipe into case where it was.

Supply electrolyte

If liquid level is too low, you shall complement distill water, no tap water, no river water or well water to prevent impurity from the failure of self-discharging; Do not complement electrolyte, otherwise the concentration of electrolyte will increase to shorten the life of battery. The liquid level can not be too high in order to prevent liquid to overflow to cause short circuit. After adjust liquid level, to charge the battery more than half an hour to mix both electrolyte and distill water equally, otherwise there is possible to freeze in battery in winter.

Check electrolyte for density

The density of electrolyte vary with the level of charging or discharging of battery. Decrease of density of electrolyte means that battery had discharged. To know the level of discharging of battery, you should measure the density of electrolyte of each cell.

(1) Screw off each cover of cell, sip liquid up by densimeter until floater float up. Read scale by your eye parallel with density and let floater locate central position and not to touch with pipe wall, to avoid influencing reading accuracy.

If temperature is lower than 25°C or upper than 25°C, measure actual electrolyte temperature with thermometer to modify the density value of it.

(2) Modification of electrolyte density. There is some error of electrolyte density among different temperature, so it is necessary to modify the measured density value. Normal density refers to the value of 25°C. When measuring, if the temperature is upper or lower than 25°C, each 1°C higher, add 0.0007 to measured value. on the contrary, each 1°C lower, subject 0.0007 from measured value.

25°C electrolyte density calculated as following formula:

$$D_{25} = D_t + 0.0007(t - 25)$$

D_{25} — 25°C electrolyte density

D_t — t°C measured electrolyte density

t — electrolyte temperature when measuring density

5.3 Battery charging

(1) Initial charge (our products has been initially charged normally, users could not do this work)

The result of initial charge has a rather important influence to battery, a certain of experience is necessary for operator to do this job.

Unused battery should be initially charged before use.

.Wipe battery exterior clean to check damage before initial charge.

Open cover of oil inlet to ensure vent hole to open.

Under the condition that the charger can work normally, infuse battery with vitriol electrolyte, of which the density is 1.26 ± 0.005 (25°C) and the temperature is under 30°C, and the fluid level must be 15~25mm higher than guard board.

Put battery standstill for 3~4 hours not exceed 8 hours. After temperature is lower than 35°C, initial charge can be made. if the electrolyte level descends after put standstill, it is necessary to be complemented.

Only electrolyte and distill water which accord with EN standard can be adopted to make up sulphuric acid electrolyte (Do not use industrial sulphuric acid and tap water).



Warning: Slowly infuse strong sulphuric acid into distill water and stir liquid by a glass rod or lead cover wood stick, do not infuse distill water into sulphuric acid absolutely, otherwise, there will be liquid boiling and splashing to injure people.

To be sure the polarity of connection between charger and battery is correct, that is anode to anode and cathode to cathode, a reliable connection is necessary.

The first stage of initial charge use 0.5I₅A (D-600 battery is 60A) until voltage of single cell is up to 2.4V, then begin the second stage;

The second stage of initial charge use 0.25I₅A (D-600 battery is 30A);

The temperature shall not surpass 45°C for electrolyte during charging, have charging current or stop charging when the temperature almost reach 45°C, wait until temperature is below 35°C, then charge again. But the charging time needs to be prolonged.

Indication of enough charging: voltage is 2.6V in second stage of initial charging meanwhile voltage change is less than 0.005V; density is up to 1.28±0.005(25°C), there is no evident change within 2 hours and a lot of fine and closely bubble occurs. The Charging capacity is 4 ~ 5 times of rated capacity and the charging time is 70 hours.

To check density of electrolyte of each cell during charging last stage to control percentage of sulphuric acid in electrolyte. If necessary, to regulate by distill water or 1.40 density sulphuric acid to manage electrolyte density and liquid level to normal value.

After finishing initial charge, clean battery surface and cover oil inlet.

(2) Normal charge

Do not use uncharged battery. Please watch out for discharge during battery charging. If discharge exceed standard value, charge it please. Excessive discharge (voltage is less than 1.7V/cell) is prohibited absolutely. Stop discharging when electrolyte density decreased to 1.17 and recharge it in time. Do not stop charge randomly during charging course.

In normal charging, Open cover of oil inlet, check if the electrolyte level is in normal height, otherwise regulate it to the normal height by distill water.

Connect charger to battery correctly, anode to anode, cathode to cathode, absolutely no error.

Charger is special to suit battery, it can regulate charging current automatically according to battery capacity until full of charging. (consult to charger manual instructions)

Suggest to build record of charge/discharge for each battery to favour knowing battery in time. During charging, to record current, total voltage, each cell voltage (with code), electrolyte density and temperature (with 0~100°C mercury thermometer) every 1-2 hours.

It tells you full of charging when there are lot of fine and closely bubble in electrolyte and voltage of cell is stable between 2.5-2.7V and there is no increase for density for terminal voltage within 2-3 hours. If one or two cell emit bubble weakly or no bubble, please find out and record it.

Do not exceed 45°C for electrolyte temperature during charging. If temperature close to 45°C, stop to charge until temperature is below 35°C.

During charging ending, check and regulate density of electrolyte. If density is abnormal, draw out some electrolyte, then infuse some to regulate: if original liquid density is too low, regulate by density 1.40 electrolyte; if too high, regulate by distill. Difference of electrolyte density of each cell is less than 0.01, liquid level shall also be normal. after adjust density, charge battery 0.5 hour with low current to mix electrolyte equality, then check electrolyte density again and adjust it if necessary.

(3) Balance charging

Under normal situation although each cell of the battery runs under the same condition, there are still reasons lead to that their capacity can not be exactly the same, so, balance charging is necessary to eliminate difference among cells. It's easy to do the balance charge according to charge manual instruction.

Normally, battery need balance charge every 2~3 months. Balance charging is also necessary for battery which is out of work for long time.


5.4 Installation and replacement of battery

Battery installation shall fix fastened, prohibit to overturn; Prohibit to hammer terminal and leading clips; Avoid impact during transporting.

6. Hydraulic system

6.1 Summary

Hydraulic system consists of pump, multiway valve, lift cylinder, tilt cylinder and pipeline ect. See figure 2-46,Hydraulic liquid supplied by pump and multiway valve distribute liquid to each cylinder.



- | | | | |
|-----------------------|-------------------------|---------------------|---------------------|
| 1.oil tank | 2.Oil absorption filter | 3.oil pump | 4.oil pump |
| 5.multiple unit valve | 6.Brake master pump | 7.steering device | 8.Steering cylinder |
| 9.governor valve | 10.relief valve | 11.lifting cylinder | 12.tilt cylinder |

figure2-48 Hydraulic system diagram


6.2 Oil pump

Oil pump is gear pump

6.3 Multiway valve

The multiway valve is two piece four body in pattern,the high pressure oil from working pump is distributed,by multiway valve rod,to lifting cylinder or tilting cylinder.The safety valve,which can control the pressure of the system,is set on the upper side of multiway oil-in mouse.The self-locking valve, main function is to prevent the terrible result caused by mishandling the controlling rod when there is no pressure source for tilting cylinder,is set on tilting valve piece. @ there are one way valves fitted between inlet and oil suction inlet of lifting valve slice and between inlet of lifting valve slice and inlet of tilting valve slice.

Multiway valve outline Figure 2-49.



1. Safety valve 2. Inching switch support 3. Spill pore 4. Lift timing sensor cover
figure 2-47 Multiway valve outline

(1) Operation of Slide valve (To tilting slide valve, for example)

(a) Neutral (figure 2-50)

In this case, high pressure liquid out of pump to tank through neutral

(b) Push slide valve in (figure 2-51)

Then, neutral channel is closed, liquid from oil inlet to open one-way valve flow to cylinder joint B, liquid from cylinder joint A flow to tank through low pressure channel, supported by rebound spring, slide valve can return to neutral.




figure 2-50

(c) Draw slide valve out (figure 2-51)

Here close neutral, liquid from oil inlet to open one-way valve to flow to cylinder joint A, liquid from cylinder B to flow to tank through low pressure channel, supported by rebound spring, slide valve can return on neutral.

(2) Motion of safety flooding valve

There is a flooding valve between pump HP and low pressure channel "LP". Pressure liquid from lifting valve "c" play on piston A and piston B, which is different area, to push both one-way valve piston K and flooding lift valve piston D to locate on their valve seating respectively. Pressure liquid of HP channel of pump play on spring of guide valve, one-way valve E can be opened. Liquid flow into low pressure "LP" through holes around valve circumference.

If open guide valve E, inner pressure of valve C decrease, both piston of valve E and valve C locate on their valve seating respectively. Inner pressure decrease because liquid which flow to rear of valve D will be cut off. oil pump "HP" passageway is in balance to inside pressure, under the effect of differential pressure, valve "D" opens, and the oil flow directly to low tension loop.




figure 2-51




Figure 2-52

(3) Motion of tilting self-locked valve

There is tilting self-locked valve in tilting cylinder valve slice to prevent mast fall down suddenly when cylinder cavity take place negative pressure and danger when mal-operating tilting valve stick. Because this self-locked valve, if even thrusting joy stick, mast cannot be tilted when forklift motor stop work. Direction of flow liquid is the same as figure 2-52, here, mast is in tilting backward. When valve core is pushed in.

(a) When pump is working, push valve core into, liquid from main pump flow into tilting cylinder through joint B, liquid returned from cylinder play on piston through oil pore A. Liquid return to tank through pore A or B of valve core. See figure 2-53.

(b) When pump is not working, push valve core into, there is no liquid into joint of cylinder B, so, pressure of point P cannot be up. So, piston cannot move, liquid of cylinder joint A cannot return to tank, cylinder cannot move. See figure 2-54.




figure 2-53





figure 2-54

(4) Multiway valve operation figure 2-55

Multiway valve operated by joy stick, all of joy stick installed on a support shaft, shaft fit on panel by bracket, joy stick steer slide valve by connector rod.



- | | | |
|--------------------------|--------------------------|----------------------------|
| 1. tilting rod operation | 2. lifting rod operation | 3. accessory rod operation |
| 4. connecting shaft | 5. connecting rod | 6. bracket |

figure2-55 multiway operation

(5) adjust safety valve pressure
Adjusted pressure for safety is 13.5/16.8MPa



Safety pressure had been set it up by manufacturer, user shall not be setup by themself.


6.4 Lift cylinder and lift chains.see figure2-56

Lift cylinder piston played on by one-way pressure, consist of cylinder shell, piston rod,piston, cylinder head etc. Two lift cylinders located on rear of outer mast,its bottom fitted on seat of lift cylinder of outer mast by pins and bolts, the top of cylinder(i.e. top of piston rod) connect with beam of outer mast.and there is speed restricting valve layed inside of the right lifting cylinder.

Piston fitted on piston rod by rebound steel wire, piston outer ring is fitted by seal and brace ring.

There is a stop valve on bottom of cylinder, when mast is up, if high pressure pipe burst suddenly, this valve can provide safety protection.

There are steel-backed bearing and seal on cylinder head to brace piston and prevent dust.




- | | | | |
|-------------------|-----------------------|----------------|----------------------|
| 1. anti-dust ring | 2. axes seal | 3. steel cap | 4. O-ring |
| 5. bearing | 6. cylinder | 7. piston rod | 8. adjusting bushing |
| 9. O ring | 10. spring | 11. circlip | 12. spring seat |
| 13. piston | 14. support ring | 15. valve core | 16. circlip |
| 17. hole seal | 18. check valve | 19. circlip | 20. valve |
| 21. O ring | 22. speed limit valve | 23. O ring | 24. pin |
| 25. chain joint | 26. nut | 27. chain | 28. chain wheel |

figure 2-56 lifting cylinder and chain

■ Stop valve motion principle

There is a stop valve on bottom of cylinder (figure 2-57), if high pressure pipe burst suddenly, this valve can prevent load lowering sharply. Liquid from lift cylinder flow through stop valve slide valve, between two cavities, there is difference of pressure produced by oil pores around slide valve; when pressure difference is less than spring force, slide valve has no motion; if high pressure pipe burst, there is a big pressure difference to push slide valve plug up oil pores around itself, only allow a little oil to flow through the pore of end of slide valve to make fork lowering down slowly.



6.5 tilt cylinder

Tilting cylinder, whose piston rod connects to mast through earbob, is double-acting in pattern. The bottom of tilting cylinder connects to framework with pin. There are two tilting cylinders on each side of forklift.

Tilting cylinder consist of piston, piston rod, cylinder body, cylinder bottom, guide sleeve and seal, piston and piston rod constructed by welding, there is a bearing and two h seals fitted on piston outside end, there are shaft sleeve, Yx seal, retainer ring and dust-ring in guide sleeve, this shaft sleeve support piston rod, seal ring, retainer ring and dust-ring to prevent leakage and dust, it is screwed onto cylinder body with O ring. See figure 2-59

Skid valve pushing forward, high pressure oil comes in from bottom of cylinder, so as to push piston forward to make mast tilt forward. Pulling backward skid valve, high pressure oil enters from front of cylinder body, pushing piston backward to make mast tilt backward.





figure2-59 tilting cylinder

8.6 Hydraulic oil cylinder

Hydraulic oil tank is installed in rear right of framework. There are net filter in oil tank and breather on oil tank cover .see figure 2-60




- | | | |
|-----------------|-------------------|--------------------|
| 1. dipstick | 2.bolt | 3.washer |
| 4.spring washer | 5. Sealing gasket | 6. Combined washer |
| 7. drain plug | 8. meshy filter | 9. Tank cap I |
| 10. Tank cap II | 11. oil tank | |

Figure 2-60

6.7 Hydraulic oil pipeline

Hydraulic system hydraulic oil pipeline. See figure 2-61.



- | | | |
|------------------------|----------------------------|------------------|
| 1. Brake master pump | 2. hydraulic steering gear | 3. tilt cylinder |
| 4. multiple unit valve | 5. oil pump | 6. oil tank |
| 7. steering cylinder | | |

figure2-61 hydraulic pipeline

6.8 Maintenance and adjustment

Working cylinder maintenance

(1) Disassemble

Cleaning thoroughly before assembling. Dismantled parts shall be on clean paper or cloth

and don't contaminate or damage parts.

- (a) Clamp flange shell of pump by bench vice
- (b) Screw off bolt 11, rear end cover 5 and pump body 1.
- (c) Dismantle lining slice 6, drive gear 2 and driven gear 3.
- (d) Dismantle seal 7 and retainer ring 8 from front and rear end cover.

Notice: if don't renew seal, please do not remove it from front end.

(2) Inspection

Use gasoline to clean parts (except rubber parts).

(a) Pump body inspection

If contact length between pump body and gear is more than 1/2 circumference, please replace pump body.




Figure 2-62




figure 2-63

(b) Lining slice inspection

Check interface of lining slice, if surface damage or thickness of lining slice is less than normal value: 4.94mm, please replace it.




Figure 2-64




Figure 2-65

(c) Front and behind pupm cover

If colour changing(brown)extent of inner surface lining sleeve is more than 150°, please replace it.

(d) Check drive wheel and driven gears

If abrasion badly, to replace a pair. If D is less than normal, replace two pair.





Figure 2-66

(e) If necessary, renew seals, lining sleeve seals, retainer ring, oil seal, clip ring.

(3) Assembling

- (a) Fit a new seal and a new spacer ring.

- (b) Fit lining slice on groove of front end cover.
- (c) Fit a drive wheel and a driven wheel on front end cover.
- (d) Fit lining slice on gear side to make groove aim at gear point. Be careful not to mistake oil inlet side and oil outlet side.
- (e) Fit a new seal and a new spacer ring on rear end cover groove. See figure 2-60
- (f) Fit rear end cover on pump body and be careful not to mistake oil inlet and oil outlet.
- (g) According to standard torque 9~10kg.m to tighten bolts.



- | | | | |
|-------------------|--------------------|----------------|--------------------|
| 1. pump body | 2. drive gear | 3. driven gear | 4. front end cover |
| 5. rear end cover | 6. lining slice | 7. seal | 8. spacer ring |
| 9. oil seal | 10. elastic collar | 11. bolt | 12. washer |

Figure 2-67 gear pump

(4) Commissioning

Commissioning includes running in pump by commissioning, checking running for normal, it is better to test pump on test-bed, but testing at forklift also to be available as follows:

(if pump abrasion badly or locking attributed to hydraulic liquid and being disassembled, you shall renew hydraulic liquid and filter before commissioning)

- (a) Fit pump on forklift and fit manometer on pressure testing mouth of multiway valve.
- (b) Release adjusting bolt of flooding valve to make pump run about 10 minutes by 500—1000rpm to ensure that hydraulic pressure is less than 10kg/cm².
- (c) Increase rev of pump up to 1500—2000rpm about 10 minutes.
- (d) Keep rev of pump between 1500—2000rpm to make pressure increase 20—30kg/cm² once every 5 minutes until up to 175kg/cm², then, make each liquid pipeline work about 5 minutes respectively, replace return filter.

Pay attention to temperature of liquid, of surface of pump and noise of running. If temperature of liquid or pump surface increase too much, please reduce load to decrease temperature of liquid, then, test again.

- (e) Flooding pressure shall be 175kg/cm² after testing. Measuring flux through lift speed.

6.9 Malfunction analysis

When hydraulic system has some failure, please consult table as below to find out cause and repair it.

Multiway valve fault diagnosis (List 2-11)

Figure 2-11

Fault	Cause	Elimination
Lift pressure too low	Slide valve get stuck	Break up, cleaning
	Oil pore jam	Break up, cleaning
Vibration Pressure up too slowly	Slide valve get stuck	Break up, cleaning
	Exhaust not enough	Exhaust enough
Vibration Pressure up too slowly	Slide valve get stuck	Break up, cleaning
	Exhaust not enough	Break up, cleaning
Liquid level less than normal	Flooding valve poor regulated	Fine-tune
Noise	Flooding valve poor regulated	Fine-tune
	Glide face abrasion	Replace flooding valve
Leak (Outside)	O ring old or damage	Replace O ring
Enactment pressure too low	Spring bad	Replace spring
	Valve base bad	Adjust or replace flooding valve
Leak (inside)	Valve base bad	Amend valve base surface
Enactment pressure too high	Valve get stuck	Break up, cleaning

(2) Hydraulic pump fault diagnosis (See List 2-12)

List 2-12

Fault	Cause	Elimination
Liquid displacement too small	Liquid level too low	Infuse liquid to normal
	Pipe or filter jam	Clean or replace
Pump pressure too low	<ul style="list-style-type: none"> ● Lining slice bad ● Brace bad ● Seal, lining sleeve seal or spacer ring badness 	Replace
	Flooding valve regulated abnormal	Regulate to normal by manometer
	Air in system	<ul style="list-style-type: none"> ● Retighten pipe beside oil inle ● Infuse liquid ● Replace pump seal
Running noise	Suction pipe bad or filter jam	Check pipe or repair filter
	Oil inlet side loose or air leakage	Tighten loose connecting
	Oil viscosity too high	Replace normal viscosity oil to adapt running temperature
	Bubble in liquid	Exhaust air and prevent air
Oil leakage of pump	Pump seal or other airproof ring bad	Replace
	Pump failure	Replace

7. Lifting system


7.1 Summarize

Lift system consist of dual mast (inner and outer mast respectively), roller lift and lower vertically, and fork.

7.2 Inner and outer mast (figure 2-68)

inner and outer mast constructed by welding. Bottom of outer mast fit on drive axle by brace.

Middle of outer mast connect with frame through tilting cylinder and it can tilt forward and backward actuated by tilting cylinder.




- | | | | |
|----------------------|-----------------------|------------------------|---------------------|
| 1. circlip for shaft | 2. roller | 3. bolt | 4. spring washer |
| 5. washer | 6. side rolling wheel | 7. gasket | 8. adjusting washer |
| 9. inner mast | 10. outer mast | 11. bearing bush | 12. Support cover |
| 13. spring washer | 14. bolt | 15. bolt | 16. spring washer |
| 17. washer | 18. pin roll | 19. side rolling wheel | 20. roller |

Figure 2-68 inner/outer mast

7.3 Fork carriage (figure 2-69)

Fork carriage move inside inner mast by main roller, main roller fitted on shaft locked by clip ring, main roller shaft also welded on fork carriage, side roller fixed on fork carriage by bolts, rolling along outside of wing board of inner mast, it can be regulated by adjust shim. In order to prevent rolling clearance, there are two fastness side roller rolling along outside of wing board of outer mast. Longitudinal load borne by main roller, when fork lift on top, upper roller appear from top of mast. Transverse load borne side roller.




- | | | |
|------------------------|------------------------|----------------------|
| 1. Load-backrest | 2.washer16 | 3.spring washer16 |
| 4.bolt | 5. Longitudinal roller | 6. circlip for shaft |
| 7. adjusting washer II | 8. adjusting washerIII | 9. Side roller |
| 10.washer12 | 11.spring washer12 | 12.bolt |
| 13. Adjust ring | 14. Side roller shaft | 15.bolt |
| 16. Side roller | 17. fork rack | |

Figure 2-69 fork carrier

7.4 Roller position (figure 2-70)

There are two rollers: outer frame roller unit as well as inner frame and fork carriage roller unit, witch is fitted on outer mast as well as inner mast and fork carriage respectively. Each roller unit consist of main roller and side roller, main roller bear load witch direction are forward and backward, side roller bear side load, both sort of rollers make inner mast and fork carriage move freely.



1. Fork carriage 2. Outer mast 3. Outer frame roller unit 4. Inner mast
5. Inner frame and fork carriage roller unit

figure 2-70 Roller position


Notice: (a) Adjust clearance of side roller for 0.5mm;
(b) Lubricate grease on main roller surface and working surface of mast.

7.5 Maintenance and regulation

7.5.1 Adjustment of lift cylinder See figure 2-71

It is needed to readjust journey of lift cylinder after dismantle or replace lift cylinder, inner mast or outer mast.do it as below:

- (1) Without regulate shim to fit head of piston into upper beam of inner mast.
- (2) Lift mast slowly to its maximum journey to check both of cylinder to move simultaneously.
- (3) Put adjusting shim into between head of piston and upper beam of mast.Shim thickness between 0.2mm and 0.5mm.
- (4) Regulating tension of chain



1. Upper beam of inner mast 2. Lift cylinder adjusting shim 3. Lift cylinder

figure 2-71 Adjusting for lift cylinder

7.5.2 Height adjusting for fork carriage(figure2-72)

- (1) Park forklift on level ground and keep mast vertically.
- (2) Keep fork bottom touching ground, make a distance A between main roller and bottom end of inner mast by regulating nut which locate upper end of adjust chain.A(A=24~29)




Figure 2-72

(3) Lowering fork on ground and tilting it backward at max. angle. Keep both of two chains be same tension by adjusting nut which locate upper end of adjust chain.

7.5.3 Replacement of fork carriage roller

- (1) Place a pallet on fork and park forklift on level ground.
- (2) Lowering fork and pallet on ground.
- (3) Dismantle the top side connector of chain, and take of the chain from chain wheel
- (4) Lift inner mast (refer to ① of figure 2-73)
- (5) Dismantle joint of upper end of chain and take off chain from chain wheel. (refer to ② of figure 2-73)
- (6) Replace main roller.
 - (a) Dismantle all of clip rings and drag main roller out by three-jaw puller, be careful to keep adjust shim safe.
 - (b) To be sure new roller is normal and fit it on its position and lock it by clip ring.




Figure 2-73




Figure 2-74

7.5.4 Replace mast roller see figure 2-74

- (1) Dismantle the fork carriage from inner mast with the same method of replacing fork carriage roller stated in 9.5.3
- (3) Tighten the hand brake, back up the rear wheels with wedge block.
- (4) Dismantle the bolts for fastening cylinder and inner mast, Sling inner mast, pay attention not to lose the adjusting pillow on the top of piston rod
- (5) Dismantle the connecting bolt between lifting cylinder and inner mast, dismantle the lifting cylinders and the oil pipe between them, not to loose the oil connector .
- (6) Lay down the inner master, dismantle the main roller on the bottom of inner mast. then, the main roller on the upper side of outer mast will also show out from the top of inner mast.

- (7) Replace main roller
 - (a) Dismantle the upper side main roller with drawing tools, Not to lost the adjusting pillow
 - (b) Install the new roller together with the djusting pillow dismantled in step(a)
 - (8) Sling the inner mast until all of the engaged in it.
 - (9) Install the lifting cylinder and fork carriage adverse to the steps as dismantled.
- 7.6 Instructions of installing accessories

⚠ If user need to assemble accessories on truck, please inform our company, do not assemble them by yourself.

8 Disassembling and installation

8.1 Attentions

- (1) Only qualified person can maintain or dismantle forklift.
- (2) Before dismantling and inspecting, park truck level and wedge truck to prevent moving suddenly, meanwhile, turn main switch off and cut battery off.
- (3) Before dismantling and inspecting,remove matel ring ,watch and other metal item from you to prevent suddenness short circuit.
- (4) During disassembling, please use normal tools, use special appointed tools when requested.
- (5) Choose optimum elevating equipment to hoist parts dismantled to prevent danger.
- (6) Check slings for safety. Keep slings tension during lifting.
- (7) Be careful to prevent falldown of heavy parts attributing to unbalance during disassembling operating.

8.2 Hoisting location for parts disassembled

- (1) Hoisting directions for lifting system see figure 2-75

Type	outline dimension length×width×height (mm)	Weight(kg)
FE4P16-18N	2200×1380×585	1200




figure 2-75

- (2) Roof guard hoisting directions see figure 2-76

Type	outline dimension length×width×height (mm)	Weight (kg)
FE4P16-18N	1398×1048×1375	85





figure 2-76

- (3) Hoisting directions for Counterweight see figure 2-77

⚠ The hoisting ring on counterweight can only be used to hoist counterweightnot to hoist entire vehicle.

Type	outline dimension length×width×height (mm)	Weight (kg)
FE4D40	1068×112×440	234
	1138×329×1215	450



FE4D45	1068×112×440	234
	1138×329×1215	600
FE4D50	1068×112×440	234
	1138×329×1215	742




figure 2-77

(4) Hoisting for battery box See figure 2-78

Type	outline dimension length×width×height (mm)	Weight (kg)
FE4D50	1048×913×866	1840
FE4D45	1048×913×866	1840
FE4D40	1048×913×866	1740




figure 2-78



Battery has the function of counterweight,so users can not replace it at will otherwise it will affect the balance of entire vehicle and other performances.

(5) Hoisting directions of travel motor see figure 2-79

Type	outline dimension length×width×height (mm)	Weight (kg)
FE4D40-50	416×329× ϕ 296	112




figure 2-79

(6) Hoisting directions for working motor see figure 2-80

Type	outline dimension length×width×height (mm)	Weight (kg)
FE4D40-50	335×293× ϕ 237	71




figure 2-80

Chapter three Operation,use and safety for forklift

I 、 Driving and operation

There are some information for operating normally as below and it favor you about good running performance, using safely, running economically.

1. Usage of new vehicle



All of the parking parts from the new vehicle should be reclaimed according to the establishment of local government.

In order to insure the new vehicle can work normally, Make a trial run of it before use it.

The life-span of vehicle depends on how you begin to use your new forklift. At initial 200 hours running, please to notice as follow.



Whatever season, you have to run machine warmly before operating.

Do maintenance better in normally.

Do not abuse machine and unreason using.

2. Connection between load and stability

Under load curve, forklift take front wheel for pivot to keep balance of vehicle and load on fork, please pay attention to load centre and load capacity to keep vehicle stable.



If exceed load curve, rear wheel should be uplifted and be in danger, forklift should be overturned to lead severe injury. Saying as below figure, load close to fork prong is the same effect as increase weight. As in such condition, load shall be decrease.

3. Load center and load curve

Load centre means the distance between front end surface of fork and cargo cg. Said figure of load curve show you relation of 2t forklift load centre and permitted load. figure of load curve is adhibited on vehicle, if figure damaged, to renew it in time.



If forklift is equipped disposal accessories such as side-move device, scraper bucket or rotating fork, its permitted load is less than normal truck(no any accessories), the reason as follow:

(1) Subtract load from rated load, its weight equal to weight of accessories.

(2)由 Because accessories length lead load centre to move forward, rated load is also decrease.

Accessories equipped lead load centre moving forward, this phenomena is called "Load centre loss".

Do not load exceeding the rated load shown by figure of load curve pasted on vehicle or accessories.

4. Forklift stability

There are regulations in ISO or other standard about forklift stability, but said regulation is not applicable for all of running condition, forklift stability vary on different running condition.

Maximum stability is assured under below condition:

(1) Level and firm ground.


(2) Running under standard load or unloaded condition.

Standard no-load state: Fork or other bearing accessories lie 30cm upto ground,tilting mast backward enough without load.

Standard load condition:Fork or other loading accessories lift up about 30cm from ground,rated load on standard load centre, mast tilting backward to max.angle.



When loading,keep min.tilting angle forward or backward as can as possible, do not tilting forward unless load fixed on load backrest or



rigidity loading goods frame, or low lift height.

5. Transporting and loading for forklift
(1) Transportation of forklift



·Transporting with truck,Wedge forklift wheel or tighten forklift by rope to prevent it moving during transportation.

·Pay attention to obey regulation of full-length, full-width, full-height of forklift during transportation on traffic road.

- (2) Loading and unloading for forklift



·Please use gangplank with enough length, width and intensity.


·Brake lorry firmly and wedge wheel.

·Gangplank shall be fixed on middle of carriage firmly, no grease on gangplank.

·Both height of left and right gangplank shall be same.

·Do not turn or transverse move during operating on gangplank.

·When loading on lorry, in order to let forklift board on simultaneously, please backing lorry slowly.



6. Preparation before driving

(1) Check position of direction switch handle⑤,and push it to neutral position(N).

(2) Turn on ignition key

Catch hold of handle of steering wheel,then turn on ignition key and keep it at “ON”position.



·Even after ignition key is turned to “ON”position,1 second is needed between brake circuit starting to work and starting to move.

·If gear shift lever is in forwardposition“F” or backwardposition“R”,before turn ignition key to“on”position,push gear shift lever to neutral position“N”

·Do notice that if step down accelerating paddle suddenly,vehicle will probably accelerate suddenly.

(3) Tilting backward of mast

Pull backward lifting handle to lift fork

150-200mm upto ground,and pull backward tilting handle to tilt mast backward.

(4) Operation of direction switch handle⑤

Direction switch handle decide travelling direction (forward-backward)


Forward F:push forward direction switch handle

Backward R:pull backward direction switch handle

(5) Loosen parking brake handle

Step down brake paddle

Let go parking brake handle forward entirely,catch hold of steering wheel with left hand,put right hand lightly on steering wheel too.





7. Steer

(1) Starting up

Move food away from brake paddle and step down accelerating paddle slowly,then,the vehicle will start to move.

Acceleration rate is decided by how much accelerating paddle is stepped down.



⚠️ · Do not startup or brake suddenly to prevent cargo falling down .

(2) Speed slow down

Release accelerator slowly. If necessary, step brake pedal down. Except emergency brake, release accelerator to make slow down slowly until parking. If even release accelerator suddenly, emergency brake is also impossible. When emergency situation, step brake pedal down to make emergency brake.

⚠️ · Please slow down if situation as follow:

- (a) turning at crossing.
- (b) Closing to cargo or pallet.
- (c) Closing to goods pile.
- (d) Traveling through narrow chunnel.
- (e) Ground/Road surface is bad.

· When backing forklift you have to look at rear direction to be sure condition is safe.

It is dangerous when backing forklift depending only on rearview mirror.

(3) Turning

It is not same as car, forklift depend on rear wheel to turn. When turning you shall be slow down and be careful for tail swing of forklift when operating steering wheel.

⚠️ · During turning, when turning radius is small, the fast speed the forklift is, the more possibility the forklift overturn. Be careful for this situation.

(4) Traveling and lifting simultaneously (Inching operation)

- (a) Traveling first, let fork prong be close to goods about 3—5m distance.
- (b) Step brake pedal down perfectly.(standstill)
- (c) Step accelerator down to be in optimum speed.
- (d) Operating lift and lowering handle to operate fork

to be lifting operation.

⚠️ · Traveling and lifting simultaneously (Inching operation) is a professional work to ask forskilled operator. Be definite to know well the shape and cg of goods to identify the vehicle stability, make a slow lifting and lowering performance of the vehicle,and please be careful in operation.

·Tilting fork to operate when fork is at a much height is very dangerous , except for fork's in and out operation , please do not operate the vehicle on the load stage.

·In order to reduce the danger of tilting fork to operate when fork is at a much height,make lifting operation when the vehicle is very close to load stage.



8. Parking and temporary parking

⚠️ · Parking safely

·Parking place shall be broad and level as much as possible.

·When unladed forklift have to park on ramp, please make mast face downward and block wheel by wedge.

·Parking vehicle outside workplace or qualified place.

·If necessary, to use signs or signal light.

·Parking on firm and level ground.

·If fork can not lower because of fault, hang



cloth on fork prong forward dead corner.

- Pay attention for road surface slide or cave in.
- To lower fork after parking perfectly, it is very dangerous to lower fork during traveling.

- Do not jump off vehicle.

- When get off forklift, you have to face vehicle and take favour of footboard.

- Slow down first and step brake pedal down and standstill and put gearshift on “N”.

- Parking vehicle at place where is

convenient to other vehicle and operating as follow:

(a) Pull backward the parking brake handle enough to its position,actuate the parking brake.


(b) Let fork lower to make it touch ground.

(c) Turn ignition key to“off”position.

(d) Take off key and keep it carefully.

(e) Be careful to get on or get off vehicle.

(f) Parking forklift

 ·When get off forklift, pull brake handle up and to tilt mast forward. Lower fork on ground. When parking on ramp, block forklift by wedge.

- When leaving forklift, take ignition key

9. Usage of battery

(1) Charging battery

To choose right charger according to instruction of operating manual.

(a) Keep liquid on normal level.


 ·Keep liquid level on normal situation to prevent battery from being over-hot or being burn out.

- If electrolyte is not enough, the life-span of battery will be shorten

(b) Infuse distill water.

(c) Do not overcharge.

(d) Charging place shall be ventilated enough.

 ·Battery charging shall be at ventilated and dry place.

(e) Open battery cover.

 ·There is hydrogen to be generated when charging,so and please open battery cover.

(f) Check terminal, cable and connector.

 ·Before charging, check connector and cable to ensure there is no injury

- Not charging under the situations as follow:

- Connector terminal has been injured.

- There are rust and abrasion in Terminal and cable.


These situations will lead spark to burn and to explode.

(g) Charge after turning off ignition key.

(h) Check proportion

Before charging, check each cell for electrolyte proportion to detect for abnormal condition to prevent certain accident happen.

(i) When pulling out or insert power connector, hold connector or handle not the cable.

 ·Do not pull out cable.

- If cable and connector failure, please inform manufacturer to replace by new one.

(j) Break up charging procedure

⚠ ·According to 《operation and maintenance manual》 of the used charger to break charging procedure.

·Do not pull out charger plug during charging, otherwise there will be spark take place to lead to danger.

(2) Replace battery

When forklift has been used continuously for a working period and the battery has entirely exchanged,replace the battery with another fully charged one and charge the battery been replaced.

⚠ ·In replacing, to be sure that new battery mates with forklift well, otherwise there will be dangerous to shorten lifespan of forklift or overturn during traveling.

·Replacement of battery shall be done on level table.

According to the steps as below to replace battery:

⚠ ·When using another forklift as hoisting equipment to lift battery, you shall choose a proper lifting tool(accessary).

·Only qualified person can operate battery.

(a) Pull out plug of battery.

(b) Open upper cover of battery.

Use gas spring or other methods to ensure block upper cover of battery to avoid cover fall down to injure human or bodywork.

(c) When hoisting battery out forklift, be careful for touching steering wheel or other forklift parts.

(d) After finish installation of battery, connect and fasten the battery pin.

(e) Close upper cover of battery.

⚠ · When close upper cover of battery, be careful to injure your finger.

·During hoisting battery, be careful to prevent swing of battery box to injure bodywork.

10. Stacking

⚠ ·Check the following items before operation:

(a) Be sure that there are no falling of load and damaging of load in loading region.

(b) Be sure that there is no goods or pile possible leading to unsafety

Stack as follows:

(1) Slow down when getting close to goods.

(2) Parking in front of goods.

(3) Check the safety of goods area.

(4) Adjust the position of vehicle until it lies in front of goods




(5) Make Mast vertically ,lift fork up more than the height of goods.

(6) Check goods'location and park the vehicle to optimum position.

(7) Ensure that the load higher than the stacked goods and lower fork slowly and place load correctly and safely.

·Before load placed on shelves or bracket:

(a) Lower load until fork no longer carry any load.



(b) Backing forklift for distance of 1 / 4 length of fork.

(c) Lift fork 50—100mm up and drive forklift forward for stacking to be optimum.

(8) Look at rear space, backing forklift in order to avoid impact between fork and pallet or goods.

(9) Ensure fork prong to be off goods or pallet, lower fork to avail driving.(from ground 150—200mm)

11. Unstacking

Unstack referring to the procedure as below

(1) Slow down when close to goods.

(2) Park in front of goods(30cm between goods and fork prong)

(3) Adjust the vehicle position in front of goods

(4) Be sure that there is no overloading.

(5) Adjust the Mast upright to ground.

(6) Observe the vehicle position and move it forward until the fork inserts the pallet completely



When it is difficult to insert the fork completely into pallet:

(a) Inserting 3 / 4 length of fork and lift pallet little more (50—100mm), then pull fork out pallet 100-200mm, then lower pallet.

(b) Insert fork into pallet completely.

(7) After fork insert pallet, lift pallet (50-100mm) up.

(8) Look at ambient space to move forklift backward to lower load.

(9) Lower load at the height of 150-200mm from ground.

(10) Tilt backward the mast to ensure the stability of goods.

(11) Transport the goods to destination

12 Deposit

(1) Before deposit

Before forklift deposits, clean it thoroughly, check up as following:

(a) If necessary, clean grease and oil of bodywork by cloth and water.

(b) When cleaning, check the vehicle entirely especially for hollow or damage of bodywork, if tires punctured, and if there is any nail or stone in tire surface groove.

(c) Check for leakage.

(d) If necessary, infuse grease.

(e) Check wheel hub nut and joint face between piston rod and piston for loose, check piston rod surface for injury.

(f) Check mast roller for rotation stability.

(g) Actuate lift cylinder to its max. height to let cylinder be full of liquid.



As long as there is any failure or malfunction or unsafe factor of forklift to be known, report to related person and stop using forklift until repaired.

(2) Daily deposit

(a) Parking forklift on appointed place and block wheel by wedge.

(b) Put shift gear on neutral and actuate parking brake.


(c) Take off ignition key and keep it in safe area.

(3) Long time deposit.

Based on daily deposit, please make check and maintenance according to the follow items.

(a) Considering the raining season, park the vehicle on high and rigid ground.


(b) Unload battery from forklift. even indoor parking, if the place is muggy, dry and shade-cool are necessary for the battery depositing. Charge the battery once a month.



- (c) Rub anticonosive oil on bared surface of piston rod and shaft ect.
 - (d) Cover parts prevent raining and wet.
 - (e) Startup vehicle at least once a month, install battery, clean the grease on piston and shaft, startup engine and preheating, make vehicle move forward and backward slowly, meanwhile operating hydraulic control for several times.
 - (f) In summer, do not park forklift on floppy surface such as asphalt ground.
- (4) Operation after long time deposit.
- (a) Take off dampproof cover.
 - (b) Cleaning pickling oil from bared parts.
 - (c) Cleaning impurity and water of hydraulic tank.
 - (d) Install full charged battery on forklift andconnect it.
 - (e) Check carefully before startup.

II 、 Using instruction of operating devices

1. Components,schematic diagram for operating devices (see following figure)



- | | | |
|-------------------------|-------------------------|--------------------------|
| 1. overhead guard | 2. rearview mirror | 3. instrument |
| 4. steering wheel | 5. Multiple valve lever | 6. Emergency stop switch |
| 7. seat | 8. Battery box cover | 9. battery |
| 10. traction pin | 11. rear wheel | 12. balance weight |
| 13. rear combined lamps | 14. electronic control | 15. side plate |
| 16. hood | 17. accelerator pedal | 18. Service brake |
| 19. parking braking | 20. tilt cylinder | 21. fork rack |
| 22. fork | 23. lifting cylinder | 24. mast |
| 25. cornering lamp | 26. head lighting | 27. lift chain |


2. Instrument unit

see figure 2.4 Electrical system (page 30).

3. Switches

(1) Emergency stop button

When emergency, press red mushroom-head button down to cut off power to stop function of traveling, turning, lifting. To resume the function, rotate the button according to the arrowhead indication.



Emergency switch

(2) Key switch

key can turn on or turn off controlling power

Turn off (OFF): In this position, power is cut off and key can be inserted and pulled out

Turn on (ON): Turn forward from off position, switch is turned on, forklift starts up.




Do not turn on ignition key and step accelerator down simultaneously.

Take off key to prevent unqualified operating when get off forklift.

Take off key when charging or parking to prevent unqualified operating.

(3) Switch unit

Switch unit is combined by direction switch, steering switch and big and small light switch.



1- direction switch

2- steering switch

3- big and small light switch

Direction switch controls travelling direction and delivers signal to instrument to display. Push handle forward, vehicle travel forward, and pull handle backward, vehicle travel backward. Neutral position is vacancy. When handle is on backward, back-up light and caution light will open, back buzzer has sound.

Steering light shows rotation direction of forklift, when handle is on turning position, steering light will blink.

push forward	left steering light is bright
middle	neutral
pull backward	right steering light is bright

Big and small lights switch control relevant lights. Small light will open when rotate to the first gear, both big and small lights will open when rotate to the second gear.

light \ gear	OFF	first gear	second gear
width light	×	○	○
tail light	×	○	○
fore light	×	×	○

○: lightening ×: blanking

(4) Rear big light switch

Tail light switch is a single gear which controls on&off of the light. Pull switch up, light open; push down, light off.

4. Control

(1) Steering wheel①and steering wheel handlebar②

Steering wheel operation is traditional: steering wheel turn right, vehicle move right; steering wheel turn left,vehicle move left. There is steering wheel at backside of forklift to make backside of forklift swing toward outside when turning.


When turning, catch steering wheel by left hand and right hand on steering wheel or control handle of multiway valve.

Both hydraulic steering system and steering wheel tilting device are standard equipment of forklift.




·According to driver seat to adjust steering wheel to optimum angle.

·Lock steering pipe by tilting handle after adjusting steering wheel tilting angle.



(2) Horn button④

Push down rubber cover located in the center of steering wheel to make a buzzing sound. Even when ignition key is turned off,the horn can also sound.




(3) Direction switch handle⑤

Indicate travelling direction

Travel forward (F): Push forward handle and step down accelerating paddle

Travel backward (R): Pull backward handle and step down accelerating paddle

When parking forklift,direction switch handle should be put in neutral position(N).




(4) Parking brake handle ⑥

In order to prevent forklift from moving, when park forklift, pull up entirely parking brake handle. It is necessary to push parking brake handle to end before driving.



·When operating the parking barke handle, step down the parking paddle.



(5) Brake paddle ⑦ and accelerating paddle ⑧





·Do not step accelerator pedal suddenly to prevent the vehicle from starting or accelerating suddenly.

·Ensure your foot remove from accelerator pedal when step brake pedal down.

From left to right, there are brake paddle ⑦ and accelerating paddle ⑧ in turn.

Step down accelerating paddle slowly, forklift speed is decided by stepped angle of accelerating paddle.



(6) Lifting handle⑨

Pull backward lifting handle, fork lifts, and push forward lifting handle, fork lowers. Lifting and lowering speed depend on tilting angle of handle, the larger the angle, the faster the speed is.



Lifting operation can't be made, if push or pull lifting handle when turn on ignition key.


Don't lower fork suddenly or stop suddenly when lowering fork.

(7) Tilting handle⑩

Pull backward tilting handle, mast tilts backward; push forward tilting handle, mast tilts forward. Tilting speed is decided by tilting angle of handle, the larger the angle is, the faster the speed is



When turn ignition key on, push or pull tilting handle, you can not tilt mast.




5. Truck body

(1) Seat

Make you fit to drive seat by adjust operating handle.

Lock will be released after pull the handle up. you can move seat to and fro gently. To be sure seat locked after adjusting.

Seat adjusting range To and fro is 120mm. When traveling on dry cement road, driver is given a perpendicular acceleration is 2.130m/s²-2.237m/s², integrative acceleration is 2.252m/s-2.356m/s.



(2) Roof guard



Roof guard protect you from falling down of goods. Its top is a fence-type shape, the space between two bars is 150mm, so, if goods size is less than 150×150mm, you have to adopt another measure to protect yourself from danger of falling down of weights. Abnormal installation of roof guard or no roof guard or changing roof guard shall lead terrible accident.

(3) Goods rest



Goods rest is an important device to protect operator from being impacted when cargo slides toward operator. Loose installation, usage after dismantling and usage after modification are all dangerous.

(4) Traction rod

Only in the following situation shall be possible to use traction rod.

- To escape from the trouble of being not able to travel(for example wheel trapped in ditch)
- Forklift need to be loaded on or be unloaded from lorry.

⚠️ ·No using for towing or to be towed operation absolutely.

(5) Fitting pin for fork

Fork fitting pin lock fork on certain position. When need to regulate clearance of fork, pull pin out up, rotate pin 1 / 4 circle to make fork at position required. Regulation of clearance of fork depend on goods need to be loaded .

⚠️ ·According to principle of goods gravity centre shall be on centre of vehicle, we have to regulate space of forks for equal distance either left and right.after regulated, to fixup fork by fitting pin firmly.

· When adjust space of fork, lean against your body on goods rest, after standing stably,push fork by your foot. Do not regulate by your hands absolutely.

(6) Foot pedal and armrest

There are foot pedal on each side of forklift, armrest located on left front brace of roof guard, when get on or get off,please use foot pedal and armrest to ensure your safety.

(7) Lamps

There are head light and front light assembled on the head of vehicle direction indicator lamp, parking light, width light). Also there are back light assembled on backside of vehicle which consists of tail light, turning light, brake light, parking light, back light and flasher.

⚠️ ·Identify the working status of lamps, Replace and repair lamps immediately if lamp burning out, lamp shield injury or dirty.

(8) Rear view mirror

Rear view mirror locates in right of roofguard front beam.

⚠️ ·Keep rearview mirror surface cleanness.
·Regulate rearview mirror for good position in favor of good sight of driver.



(9) Battery plug

Battery plug is used to join or cut off power, in normal situation, it should always be connected.

⚠️ ·If checking electrical parts of inside location, please cut off power to prevent danger.

·Even if ignition key on “OFF”, main circuit Still has voltage.if you want to switch off power,it is necessary to pull out this connector.

·Do not pull out plug of battery during Driving unless emergency, because it can lead steering malfunction.



III、 Safety issues

Safety is your business and responsibility. This section describes the typical forklift often used in the basic safety regulations and warnings, but also applies to the door frame with special specifications.

1 Operation place and working environment

(1) Ground conditions

The operation place of forklift should be ground with flat and firm surface, a good ventilation is needed.

Forklift's performance depends on the situation of the ground; running speed should be adjusted appropriately in ramps or rough pavement to be especially careful when driving. Driving on a ramp or rough roads will speed up the forklift tire wear and increased noise.

(2) Work environment

Forklift use ambient temperature should be $-20^{\circ}\text{C} \sim 40^{\circ}\text{C}$, the ambient humidity should less than 80%.

(3) Weather condition

When it's rainy, snowy, foggy or windy, to assess the safety before use forklift, the best is not to use for out door work, if must, driving and operation should be more carefully.


2. Safety rules



Only qualified people who has been trained and has driver license can operate the forklift!



Forbid to drive on the highway!



Put fatigue dress on before driving!


Vigilant: injuries, the ambulance!



Do not change parts on forklift arbitrary without permission.



Read the instruction manual carefully before driving!




Turn off the engine before maintenance!




Understand traffic regulations



Before use, please check on the truck!




Do not move the overhead guard!



To keep driver's cap clean!




Do not drive an unsafe forklift!



Drivers should have a healthy body!



Be sure your truck is safe!



Work in specified area



Do not drive a damaged truck!



Hold tightly when get on the truck!



Start forklift correctly!



Adjust seat before driving!




Make sure your forklift is in safe operating condition!



Appropriate fasten seat belts!




Always pay attention to the height of work place!



Turn on lights in dark area!




Do not put arm and body outside of the overhead guard during work!



Avoid driving on soft ground, only allowed to run on solid and flat ground.




Keep body under the guards!




Avoid eccentric loading!




Pay attention to encounter item by front fork when loading!




Check fork pin position!




Note the security of the work region!



Do not run on smooth or slippery ground!



Note the horizontal driving stability of the truck when it is un-load!



Be especially careful when handling long



Forbid handling people!


or wide cargo!



If can not see the front when turning, please whistle and drive slowly.



Use appropriate pallets or sleeper when handling small objects!



Do not chase each other through the traffic!




Not allowed to stand on the goods!



Not allowed to gaze around while driving!



Do not use the forklift to do stunt!




when goods is so high to keep out line of sight, drive backward or forward under



Should obey the traffic rules and all warnings and signs!

direction of others



when loading, travel forward in upgrade and backward in downgrade



Pay attention to the steep uphill slopes and goods lifting height!



When no-load, travel backward in upgrade and travel forward in downgrade!



Note using brake when start truck on the slopes!




Not turn when driving on a slope!



People or things moving on road should be warned by whistle!



Be careful to crush people or goods when turning!



Operators are not allowed to close when the truck is working!



While turning a high speed can cause accident because of unstable center of gravity!




People are not allowed to start in work place!




Notice the change of rated load weight before use forklift.



Pay attention to the area where forklift is driven!



Use the fork correctly when loading!



Slow down when loading!



Do not move the truck when there is




It is forbidden to stand or walk under

someone in front of the truck!




Do not load the goods which is higher than the goods rest.

the elevatory fork!



Please bind the goods which is difficult to fix before load!




Do not carry the goods from forklift by manpower!



Do not let people to carry the goods have been damaged!



Do not misuse the fork!



Be careful when load the container!



Do not pick up people!




Do not misuse forklift!



Do not extend any part of body outside when driving!



Drive the truck smoothly to avoid sudden acceleration and deceleration!



Must use special equipment to lift people safely to work at height!




Do not overload!




Do not lift when there is excessive wind!



Not allowed to work in explosive environments!




The faulty trucks should be put into the indicated area!



park the forklift to the indicated area!




Do not park the forklift on the slope!




When the forklift is not in use, please do the follow.

- Brake
- Put direction pole in neutral position.
- Lower the fork to the ground
- Frame forward tilt.
- Take off the key

3. Move the truck



Forbid hoisting from the top!



Forbid hoisting on the frame!



Hoisting the forklift correctly!

Hoisting the forklift

·Tie firmly steel cable on two terminal holes of outer mast beam and on counterweight hoisting hook,then,hoist forklift with hoisting device.the side of steel cable connecting to counterweight should go through notch of roofguard without exerting pressure on roofguard.


- ⚠️ ·When lifting the truck, be sure not to wire rope and overhead guard around together.
 - Wire rope and lifting equipment to be very strong, enough to secure bearing fork lift, because the truck is extremely heavy.
 - Do not use the cab (overhead guard) to hoist the forklift.
 - Forklift upgrade, do not enter the truck underneath.
4. How to avoid overturning,how to protect yourself



Prohibit forward tilt to enhance loading, so as to avoid tipping!




Prohibit lifting goods tipsily!




Prohibit eccentric loading of goods!




To avoid driving on slippery roads!



When the truck is not in the horizontal position, do not load or unload!



Prohibit crossing the obstacle such as a trench, mound and railway!



When moving, the distance between fork and ground should be less than 150mm to 200mm!




whether load or no-load, don't turn in a high speed or in a large radius!




when no-load fork is lifted, please turn with a narrow range.



Be sure to fasten seat belts!



Do not jump in the event of forklift rollover!



Please wear helmets when driving!

! It is more safe to stay under the protection of seat belt than jump down the truck. If the forklift began to tip over:

1. Tap foot and clench the steering wheel tightly.
2. Do not jump.
3. The body bend to the opposite direction of the rollover.
4. Forward the body.

5. Safety problem in Maintenance

(1) Maintenance location

! Designated areas should be available to service providers and adequate equipment and security facilities.

- The site should be level ground.
- The site should be well ventilated.
- The site should have fire-fighting equipment.

(2) Precautions before maintenance



- No smoking
- Wear all protective equipment (helmets, shoes, glasses, gloves and boots), and suitable clothing.
- Wipe out the oil in time.
- When add lubricating oil, you should clean out dirty oil or dust with a brush or cloth, then add oil.
- In addition to the needs of some cases, should turn off the key switch and pull the battery plug out.
- Lower the fork to ground when maintaining.
- Clean the electrical components with compressed air.

(3) Matters need attention.




- You should be careful not to put your feet under the descensive fork, do not be tripped over by fork.
- When fork is lifted,place cushion block or other object under inner mast to prevent fork and mast from falling down suddenly.
- You should be careful when you open and close the noseplate and cover plate of battery.
- When you can not finish your work in one time,please make mark and go on next time.
- Use the right tools, do not use makeshift tools.
- Because of high pressure hydraulic circuit, do not carry out maintenance work before reducing the internal pressure oil-way.
- When shocked by high-voltage,search for medical treatment immediately.
- Do not use the door frame assembly as a ladder.
- Strictly forbidden to put your hands,feet and body between frame and door frame assembly.

(4) Inspect and replace tires.



- Assembly and disassembly of tires must be operated by professionals.
- High-pressure air should be carried by professional.
- Wear goggles when using the compressed air.
- When disassemble tires, do not loose rim junction bolts and nuts, there is high-pressure gas inside the tire, bolts, nuts and rims loose cause very dangerous situation.
- Junction disassembly rim bolts and nuts, the tire must be exhausted within the high pressure gas, and carried out special tools.



(5) Use jack (replacement of tyres)



- When lift the forklift truck with a jack, do not bore into the botton of forklift.
- Before lift the forklift truck with a jack, ensure there is no person or load on the truck.
- When forklift is of ground,stop using jack and put pad under it to prevent it from falling down
- Before lift forklift with jack,affirm there is nobody and no load on it

(6) Emission (electrolytic liquid, oil, etc.) requirement.



- Forklift scrapped parts (plastic parts, electrical components, etc.), liquid (hydraulic oil, brake fluid, etc.) should be recycled according to local government stipulation,do not dispose them at will.


6. Safety problem in battery usage

(1) No smoking


 **Batteries produce hydrogen gas. Short circuit will produce sparks when lit cigarette near the battery, it will cause an explosion and fire.**




(2) Avoid electrical attack

 **Battery with high voltage, when the installation and maintenance, do not touch the battery conductor, which can cause serious burns.**


(3) Correct link

 **When the battery charging, the positive and negative can not be reversed, otherwise it will cause heat, fire, smoke or explosion.**


(4) Do not put metal objects on the battery

 **Do not let positive and negative contacts cause a short circuit by bolts or tools, which will result in injuries and explosions.**

(5) Against excessive discharge

 **Do not use forklift until it can not move, otherwise the battery life will be shortened. The batteries need charging up when the battery capacity warning light flashes continuously.**

(6) Keep clean

 **Keep the battery surface clean.**
·Do not use dry cloth, chemical fiber cloth to clean the battery surface. Do not use polyethylene film covered battery.

·Static electricity can cause an explosion.

·Clean the top of the battery not covered with a moist cloth.

(7) Wear protective clothing

 **When maintain the batteries, you should wear goggles, rubber gloves and rubber boots.**



(8) Battery electrolyte is harmful



·Battery electrolyte is made of diluted sulfuric acid, be careful when handling.
·When electrolyte adhesion conglutination on eyes, skin and clothing, it will result in vision loss and burns.

(9) Emergency dealing methods



·When the accident occurred, deal according to the following methods of emergency treatment and contact a doctor immediately.

- Splash on the skin: wash with water for 10-15 minutes.
- Splash into the eyes: wash with water for 10-15 minutes.
- Contaminated for a large area: counteract(baking soda)electrolyte with dry soda or clean it out with water
- Swallowed: to drink plenty of water or milk.
- Spilled on clothing, immediately take off clothes.

(10) Close battery cover tightly.



·Cloth battery upper cover tightly to prevent electrolyte from leaking.
·Do not add too much electrolyte, electrolyte overflow will cause leakage.

(11) Waterproof



·Batteries can not be wet with rain or sea water, this will damage the battery or cause fire.

(12) Battery anomaly



·When the battery has the following situations, please contact our sales department:
·Battery stinks.
·Dirty of electrolyte.
·Electrolyte temperature becomes higher.
·Electrolyte reduces too quickly.

(13) Prohibit disassemble



·Do not drain the electrolyte from the battery.
·Do not split the battery.
·Do not repair the battery.

(14) Stored



·When the battery is not in use for a long time, it should be stored in well-ventilated place and difficult to fire.


(15) Disposal of waste batteries



·Disposal of waste batteries should contact our sales department.

7. Plate

Signs stuck on vehicle are to illustrate using method and attention matters of vehicle, which not only takes consideration of you but also of the vehicle. stick the signs plate on again if they fall of



- | | |
|-------------------------------------|---------------------------|
| 1. Battery maintenance instructions | 2. Warning |
| 3. Company identification | 4. Hoisting marking |
| 5. hydraulic fluid | 6. Model |
| 7. Squeeze marking | 8. Prohibition of lifting |
| 9. Stopping braking | 10. Life belt |
| 11. No Climbing | 12. Warning mark |
| 13. Operation prompt | 14. Warning mark |
| 15. Warning mark | 16. Data plate |
| 17. curve of load | 18. Reading hint |
| 19. Ban on manned persons | |

Chapter four Truck's regular check and maintenance

Conduct a comprehensive pre-inspection of forklift trucks and forklifts to avoid failure and fail to produce the life it deserves. Maintenance program is based on the number of hours listed in forklift work 8 hours a day, working 200 hours a month the case may be, in order to maintain safe operation and maintenance procedures should be maintained on the forklift.

Routine maintenance and repair work carried out by the truck drivers, and other inspection and maintenance by professional maintenance personnel.

I 、 The check before operation

For safe operation and to make sure the truck in good condition, a comprehensive inspection of truck should be conduct before operation, which is a statutory duty. If find problems you should contact our sales department.



·A small mistake will cause a major accident, do not operate or move the forklift truck before the completion of repair work and inspections.

·The forklift should be checked on the platform.

·When checking on electrical system of the truck, the key switch should be switched off and the battery plug should be unplug before the test.

·Replacement of inappropriate handling of waste oil down (into the water pipe under the soil, burning, etc.) will pollute the water, soil, atmosphere, etc., which is prohibited by law.


1. Checking point and checking content

	No.	Checking points	Checking contents
Brake system	1	Brake pedal	Foot brake pedal travel and braking force
	2	Brake oil	Quantity and cleanliness
	3	Parking brake	Parking brake handle travel and the size of operation force
Steering system	4	Steering wheel control	Elastic, rotation and movement before and after
	5	Hydraulic steering operation	Operation of all components
Hydraulic system and the frame	6	Function	Function, it has cracks, lubrication condition
	7	Pipe	Whether the pipe is leakage
	8	Hydraulic fuel	The appropriate fuel
Tyre	9	Lifting chain	Left and right should be consistent with two chain tightness
	10	Tyre	Pressure size, whether abnormal breakage.
	11	Wheel nut	Tighten firmly
Battery	12	Charging	Determine the battery capacity display status, the proportion of the plug should be firmly connected.
Lights, horn and switch	13	Headlights, taillights, reversing lights, horn turn signals, and emergency power off switch	To see if the light off, listening to speakers if sound, emergency power off switch is abnormal.
Detection and display	14	Function	When connected to key switch should display "test state normal"
Others	15	Owerhead guard, load backrest	Bolts, nuts are tightened
	16	Nameplate and marks	Integrity
	16	Other parts	Normal or not

2. Checking procedure

(1) Check the brake pedal


Check brake condition and to ensure a fully depresses the brake pedal when the plane from the floor counting down the brake pedal travel should be more than 50mm, no-load forklift truck braking distance about 2.5m.



(2) Check the brake oil





Open the lid and check the brake oil and other conditions.




(3) Check parking brake handle

- Push forward parking brake handle and observe following status.
- If there is proper pull journey
- Brake force value
- Damaged parts or not
- Handle operating force value is suitable to operator or not
- Operator may adjust by the screw installed on the top of handle.



(4) Check the steering wheel rotation case

The steering wheel clockwise and counterclockwise rotating gently, check whether there is rebound phenomenon, a suitable spring trip to 50-100mm. Steering wheel before and after the trips of about 7°, if the above situation, turn the steering wheel shall be normal.



(5) Check the function of steering system

The steering wheel clockwise and counterclockwise rotation, check the power steering work.

(6) Check hydraulic system and frame function

Check the upgrade and after dumping the normal operation is smooth




(7) Check pipeline

Check lift cylinder, tilt cylinder, and all pipeline whether oil leak.

(8) Check the hydraulic oil

Land the fork to the ground, check oil level gauge hydraulic oily bits, when the oil level in the H to the L range, the volume of hydraulic point oil suitable range.




model	H	L
FE4D40-50	70L	63L

(9) Check the lifting chain

Bring fork to the ground 200-300mm high, to ensure the tightness around the same chain. Check finger stick is in the middle, if different tightness can be adjusted through the chain joints.



After adjustment, should be double nuts tighten.



(10) Check tires (pneumatic tires)

Unplug the nozzle cap, measuring tire pressure with a tire air pressure. After check air pressure, nozzle mouth should ensure that gas will not leak before installed the cap.



Forklift tire pressure is higher than the car's; it should not exceed the prescribed pressure value.

	model	tyre pressure
fore tyre	250-15	solid rubber
rear tyre	21x8-9	solid rubber



Check tyre (solid tyre)

Check if there is dilapidation or leakage on tyre and its sides, and if there is deformation or damage in wheel rib and locking collar

(11) Check wheel nut




Wheel nut loosening is very dangerous, if loose, the wheels may fall off, resulting in vehicle flip. Check the availability of loose wheel nut, it is very dangerous even one of them is loose, so be screwed to the provisions of pre-torque value.

Wheel nut tightening torque


Front wheel: 250-15 539~686N.m

Rear wheel: 21x8-9 280~330N.m




(12) Check charge condition

Measuring the proportion of battery, when converted to 30 °C, the battery proportion from 1.275 to 1.285, indicating the battery is fully charged, and check whether the terminal block is loose, and whether the cable is damage.



(13) Check headlights, turn signals and horn

Check whether the normal bright lights, speakers is normal (when pressing the horn button, horn ring)
 Check whether the emergency stop is normal.



L	left steering light is bright
N	neutral
R	right steering light is bright

(14) Check instrument panel features

(15) Check the overhead guard and load backrest
 Check whether there are loose bolts or nuts

(16) Check the integrity of vehicle identification

(17) Others

Check whether abnormalities other parts



In addition to checking lights and operating conditions, the key switch must be turned off and disconnect the battery plug before check the electrical system.

II、 Check after operation

After the completion of the work remove the dirt on forklift and check the forklift according to the follow items:

- (1) Check all the parts if there is damage or leakage.
- (2) If there is deformation, distortion, damage or breakage?
- (3) Add lubricating grease according to the situation.
- (4) Let fork upgrade to the max high for several times after work. (When the daily work is not up to the fork with the arrival of the maximum height of the situation, it would allow oil flow through the tanks of the entire journey, to prevent rust.)
- (5) Replace the faulty component which caused malfunction during work.



· A small mistake will cause a major accident. Do not operate or move the forklift truck before completion of repair work and inspections.

III、 Truck cleaning



- **Stop the truck at the specified location.**
- **Pull the parking brake handle.**
- **Press the emergency stop switch.**
- **Turn off the key switch and remove the key.**
- **Disconnect the battery plug.**

1. Truck surface cleaning .



· Do not use flammable liquid to clean trucks, take safety measures to prevent short circuit.

- Use water and soluble detergent to clean the truck.
- Clean the oil filler and periphery of grease tap carefully.



If regular cleaning truck, please lubricate timely.

2. Chains cleaning



- **Do not use chemical detergent, acids or other corrosive liquid to clean the chain.**
- Place a tank in the bottom of the frame.
- Use gasoline or other petrochemical derivatives to clean the chain.
- Do not add any additive when use the steam nozzle cleaning.
- Dry immediately after cleaning of the chain pin and the water stain on chain surface.

3. Electric system cleaning



· Do not use water to clean the pump control and a variety of connectors, so as not to cause damage to electrical systems.

Use non-metallic brush or low-power hair dryer, according to the manufacturer instructions to clean the electrical system; do not move the protective cover.

4. After cleaning

- Thoroughly dry water stains on the truck (use compressed air as a example).
- Start the forklift according to the procedures.



· If moisture penetration into the motor, you must first remove the moisture, to prevent short circuits



Moisture will reduce brake performance, brake truck briefly to drying the brake.

IV、 After cleaning

- Thoroughly dry water stains on the truck (use compressed air as a example).
- Start the forklift according to the procedures.



·If moisture penetration into the motor, you must first remove the moisture, to prevent short circuits



Moisture will reduce brake performance, brake truck briefly to drying the brake.

1. Regular maintenance schedule

√—Check , calibration, adjustment ×—Change

(1) Battery

Mainten- ance item	Maintenance item	Tools	Every- day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Battery	Electrolyte levels	Eye survey		√	√	√	√
	Electrolyte specific gravity	Gravi- meter		√	√	√	√
	Quantity of electricity		√	√	√	√	√
	Terminals are loose		√	√	√	√	√
	The cable is loose		√	√	√	√	√
	Surface cleanliness of the battery		√	√	√	√	√
	Battery surface has placed Tools		√	√	√	√	√
	Ventilation cover is tightened, vent is unimpeded			√	√	√	√
	Away from the fireworks		√	√	√	√	√

(2) Controller

Mainten- ance item	Maintenance item	Tools	Every- day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Controller	Check the wear condition of contactors					√	√
	Check if contactor mechanical movement is good					√	√
	Check micro switch operation of the pedal is normal					√	√
	Check if the motor, battery and power unit is a good connection					√	√
	Check if the malfunction analysis system is normal						At the begin- ning of 2 years

(3) Motor

Mainten- ance item	Maintenance item	Tools	Every- day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Motor	Remove the eyewinker from the motor shell				√	√	√
	Clean or change bearing						√
	If Carbon brushes, commutator is worn, the spring force is normal				√	√	√
	If Wiring is correct, reliable				√	√	√
	Clearing brush and commutator surface for the film end on toner					√	√

(4) Transmission system

Mainten- ance item	Maintenance item	Tools	Every day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Gearbox and Wheel Reducer	Noises		√	√	√	√	√
	Check leakage		√	√	√	√	√
	Change oil						×
	Check the working condition of brake		√	√	√	√	√
	Check the moving of gear wheel					√	√
	Check the junction with the frame bolts loose situation				√	√	√
	Check wheel bolt tightening torque	Torque wrench	√	√	√	√	√

(5) Wheel(forward, backward wheel)

Mainten- ance item	Maintenance item	Tools	Every- day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Tyre	Wear, cracks or damage		√	√	√	√	√
	If there is nails, stone or other foreign items on tire matter				√	√	√
	Wheel damage		√	√	√	√	√

(6) Steering system

Mainten- ance item	Maintenance item	Tools	Every- day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Steering wheel	Check clearance		√	√	√	√	√
	Check axis loose		√	√	√	√	√

	Check radial losse		√	√	√	√	√
	Check operation condition		√	√	√	√	√
Steering gear and valve block	Check if mounting bolts are loose				√	√	√
	Check valve block interface with steering leak case		√	√	√	√	√
	Check seal of connectors		√	√	√	√	√
Rear-axle	Check whether the rear axle mounting bolts loose				√	√	√
	Check if there is bending, deformation, cracks or damage				√	√	√
	Check or replace the lubrication of bridge bearing.					√	√
	Check or replace lubrication of bridge bearing					√	√
	Check steering cylinder operating conditions		√	√	√	√	√
	Check whether steering cylinder is leaking		√	√	√	√	√
	Check rack and pinion gear case					√	√
	wiring and working condition of sensor					√	√

(7) Brake system

Mainten- ance item	Maintenance item	Tools	Every- day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Brake pedal	Empty run	Gradu- ated scale	√	√	√	√	√
	Pedal travel		√	√	√	√	√
	Operation condition		√	√	√	√	√
	Whether there is air in the brake pipe		√	√	√	√	√
Stop, brake and control	Whether the brake is safe and has enough travel		√	√	√	√	√
	Operation condition		√	√	√	√	√
Pole and cable	Operating performance				√	√	√
	Whether the connection is lossen				√	√	√
	Wear of reduction gearbox connectors					√	√
pipe	Damage, leakage, rupture				√	√	√
	Loose situation of connection and clamping				√	√	√

	parts						
Brake pump	Leakage situation		√	√	√	√	√
	Check oil level, oil changing.		√	√	√		×
	Pump situation					√	√
	Pump leakage, damage					√	√
	Pump piston cups, one-way valve wear damage, replace						×

(8) Hydraulic system

Maintenance item	Maintenance item	Tools	Every-day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Hydraulic oil tank	Check the oil, oil change		√	√	√	√	×
	Suction filter cleaning						√
	Exclude eyewinker						√
Control lever	Whether the connection is loosen		√	√	√	√	√
	Operation condition		√	√	√	√	√
Multitandem valve	Leakage		√	√	√	√	√
	Safety valve and self-locking tilt valve operation condition				√	√	√
	Measuring the pressure of the safety valve	Oil gauge					√
Pipeline joint	Leakage, loosening, fracture, deformation, damage				√	√	√
	Change the tube						×
Hydraulic pump	Hydraulic pump is leaking or there is noise		√	√	√	√	√
	Hydraulic pump gear wear				√	√	√

(9) Lifting system

Maintenance item	Maintenance item	Tools	Every-day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Chain and chain wheel	Check the chain tension state, whether deformation, corrosion damage		√	√	√	√	√
	Fuel chain				√	√	√
	Rivet pin and loose conditions				√	√	√

	Chain wheel deformation, damage				√	√	√
	If Bearings of chain wheel loosen				√	√	√
Attachment	Check whether in normal state				√	√	√
Lifting and tilt cylinder	Whether Piston rod, piston rod thread and the connection is loose, deformation, damage		√	√	√	√	√
	Operating conditions		√	√	√	√	√
	Leakage		√	√	√	√	√
	abrading and damaging status of pin and oil cylinder				√	√	√
Fork	Damage,deformation,wear of fork				√	√	√
	Damage,deformation,wear of allocation pin					√	√
	cracking and abrading status in hooker welding of fork root				√	√	√
Mast fork frame	welding between inner mast,outer mast and beam is cracking or damaged or not				√	√	√
	Tilt cylinder bracket and the door frame weld whether cracking, damage				√	√	√
	Inner frame, outer frame weld whether cracking, damage				√	√	√
	Fork frame weld whether cracking, damage				√	√	√
	wheel loosen				√	√	√
	Mast bearing wear, damage						√
	Mast bearing cap bolts whether loose				√		√
	Whether Lift cylinder rod bolt head, bending plate bolts loose				√		√
	cracking,damaging status of welding of roller and roller shaft				√	√	√

(10) Else

Mainten-ance item	Maintenance item	Tools	Every-day (8h)	Every week (50h)	Every month (200h)	Three months (600h)	Six months (1200h)
Overhead guard and load backrest	Installation is firmly	Measur-ing hammer	√	√	√	√	√
	Check the deformation, cracking, damage		√	√	√	√	√

Indicator light for steering	Work and installations		√	√	√	√	√
Horn	Work and installations		√	√	√	√	√
Lamps and bulbs	Work and installations		√	√	√	√	√
Reversing Buzzer	Work and installations		√	√	√	√	√
Instrument	Working condition		√	√	√	√	√
Wire	Harness injury, loosening			√	√	√	√
	Electrical connection loose				√	√	√

2. Regular replacement of key safety parts

Periodic replacement of critical safety components

When some parts difficult to find through regular maintenance of injury or damage, in order to further improve security, the user should replace the parts given in the following table for regular.

If the parts appeared abnormal before the time comes to replace, it should be replaced immediately.

Name of critical safety components	Useful life
Brake tube or hard pipe	1~2
Hydraulic hose for lifting system	1~2
Lifting chain	2~4
High pressure hose/tube for hydraulic system	2
Oil cup of brake fluid	2~4
Cylinder cover and dust cover of brake pump	1
Internal hydraulic system seals, rubber parts	2

V、Area lubricated and lubricant recommended

1. Area lubricated

○: Change

◎: reinforce

□: Check and adjust


BO: Brake fluid

FO: Hydraulic oil

GO: Gear oil

CG: Grease

W: Distilled water



2. Lubricant recommended

Name	Trademark	Capability(L)	Remark
Hydraulic oil	L-HM32	Max70	≥-5℃
	L-HV32		≥-20℃
Gear oil	85W/90GL-5	12 (single drive)	-15℃ ~ +49℃
	80W/90GL-5	3 (double drive)	-25℃ ~ +49℃
Brake fluid	Caltex DOT3	0.2	
Industrial Vaseline	2#		Battery electrode column
Grease	3# Lithium Grease		

Maintenance record

No.	Date	Maintenance content	Noter

FE4P40N
FE4P45N
FE4P50N

NOBLELIFT

NOBLELIFT INTELLIGENT EQUIPMENT CO.,LTD.

Service hotline: 4008-836115

Wechat: nuolijixie

Postcode: 313100 Email address: info@nobelift.com

Website: www.nobelift.com

Version: Jan,2019

